



# *OWNER'S MANUAL*

---

GUIDEBOOK TO ENJOYMENT OF  
YOUR VENTURE RV  
RECREATIONAL VEHICLE

---

*Sonic*

THE PURPOSE OF THE VENTURE RV OWNER'S MANUAL IS TO PROVIDE THE MOST CURRENT INFORMATION AVAILABLE CONCERNING VENTURE RV RECREATIONAL VEHICLES. OPERATION AND MINOR MAINTENANCE IS THE MAIN FOCUS OF THIS BOOK.

MAINTENANCE OF YOUR RECREATIONAL VEHICLE IS IMPORTANT TO KEEPING YOUR COACH IN GOOD CONDITION. FAILING TO PROVIDE MAINTENANCE, AS SUGGESTED, COULD RESULT IN LOSS OF WARRANTY COVERAGE. REVIEW THE COPY OF YOUR VENTURE RV TOWABLE TRANSFERABLE LIMITED WARRANTY, WHICH HAS BEEN SUPPLIED TO YOU WITH YOUR WARRANTY REGISTRATION FORM.

ADDITIONAL MANUALS MAY BE SUPPLIED AND AVAILABLE BY THE MANUFACTURER OF THE COMPONENT AND/OR APPLIANCE. SEE THE INFORMATION PACKET IN YOUR COACH.



Conventional Travel Trailer

We congratulate you on your purchase of a VENTURE RV, recreational vehicle. You have chosen a quality built RV which should provide you with many years of camping memories and fun.

The recreational vehicle you have purchased has been inspected by our trained inspectors and fully meets our high quality standards.

As the owner of a new VENTURE RV, you can rest assured that we will do all we can to keep you a "happy camper". Naturally, your selling dealership is always happy to help you with any questions you may have or service you may need. And should you need assistance when traveling, with VENTURE RV dealers nationwide, assistance is usually just minutes away.



**VENTURE RV**

0985 N 900 W  
Shipshewana, IN 46565

# TABLE OF CONTENTS

<b>Chapter 1 – Introduction to RV Ownership</b> .....	<b>1</b>
Safety Considerations .....	2
Reporting Safety Defects.....	2
Safety When Emergency Stopping.....	3
Additional Safety Considerations.....	3
Extended or Cold Weather Use .....	4
Condensation .....	4
Causes.....	4
Solutions.....	5
Interior Ventilation.....	6
<b>Chapter 2 – Service Procedures</b> .....	<b>7</b>
Basic Service Procedures .....	7
Dealer.....	8
Factory.....	8
Parts.....	8
Owner’s Responsibility .....	8
Seasonal Site.....	9
Towable Limited Warranty.....	10
<b>Chapter 3 – Using Your RV</b> .....	<b>14</b>
Equipment.....	14
Tow Vehicle .....	14
Hitches – Travel Trailer.....	14
Hitch Height Specifications – Travel Trailer.....	15
Hook-Up (Travel Trailer) .....	15
The Safety Chain (Travel Trailer) .....	16
Traveling.....	17
Weights .....	17
Weighing Vehicle (Loaded or Unloaded).....	18
Loading the Trailer—Distribution .....	18
Towing.....	20
Tires.....	20
Safety First-Basic Tire Maintenance .....	21
Understanding Tire Pressure and Load Limits.....	22
Tire Size .....	22
Tire Tread.....	23
Tire Balance and Wheel Alignment.....	23
Tire Repair.....	23
Tire Fundamentals .....	23
Vehicle Load Limits .....	24
Cargo Capacities .....	24
How Overloading Affects Your RV and Tires .....	25

How to Change a Tire.....	26
Wheel Bearings.....	26
Wheel Lugs.....	26
Brakes—Electrical .....	27
Breakaway Switch .....	27
Setting Up and Using Your Recreational Vehicle .....	28
Travel Trailer Hook Up.....	29
General Detector Information.....	30
Safety Detectors.....	30
Fire Extinguisher.....	30
Propane/ Carbon Monoxide Detector.....	31
What is Carbon Monoxide?.....	31
Dual Sensor Technology.....	31
Operation.....	31
Low Power Option.....	32
Visual and Audible Alarm Signals.....	32
CO Alarm.....	32
Propane Gas Alarm.....	33
Malfunction/Service Signal.....	33
End of Life Signal.....	33
Smoke Alarm.....	34
Operation.....	34
Testing.....	34
Steps-Two or Three .....	35
Windows .....	36
Doors.....	36
TV Antennas (Standard Roof Mount) .....	36
Slide Outs.....	38
Power For Operation.....	38
Trailer Set-Up Requirements-General.....	39
Below Floor Slide System.....	39
Above Floor Slide Out .....	39
Electrical Components.....	40
Manual Override.....	41
Below Floor Slide Out.....	41
Above Floor Slide Out.....	41
Blinds.....	41
Safe Tek with USB Charger.....	42
Murphy Bed.....	43
Flip Down Cargo Tray.....	44
<b>Chapter 4 – Systems .....</b>	<b>45</b>
Water and Drainage Plumbing .....	45
Fresh Water System.....	45
Tanks.....	45
Filling Fresh Water System.....	45

12-Volt Demand Pump .....	46
Faucets.....	47
Bath and Shower .....	47
Outside Shower (Optional) .....	47
Fresh Water Lines.....	48
Lo-Point Drains.....	48
Sanitizing and Filling the Potable Water System.....	49
For Water Lines only.....	49
Drainage (Fresh Water) .....	50
To Drain System.....	50
Sanitation System .....	50
Toilets.....	50
Using Toilet and Tank System.....	51
Vents.....	51
Holding Tanks.....	52
Draining the Tanks.....	52
Black Tank Flush System.....	53
Maintenance for Holding Tanks.....	54
Winterizing Your Recreational Vehicle .....	54
By Pass Kit.....	55
Propane Fuel System.....	56
Propane Container.....	56
Servicing and Filling Propane Containers .....	57
Installing Propane Containers.....	58
Regulator.....	60
High Pressure Hoses with Acme Connectors.....	62
Main Supply Hose – Low Pressure .....	62
Operation.....	63
Checking for Leaks.....	63
Propane Gas Consumption .....	64
Electrical System.....	66
General Information.....	66
Changes and Modifications .....	66
120 Volt AC System.....	66
Power Cord 30 Amp .....	66
Circuit Breakers and Box .....	67
GFCI Protection.....	68
12 Volt DC System .....	69
Converter.....	69
Auxiliary Battery .....	70
Circuit Breakers and Fuses-12Volt DC .....	70
Exterior Lights and Connector, 12V .....	72
Porch Lights.....	72
Brake Wiring.....	72
Furrion, Solar Panel Connection.....	73

<b>Chapter 5 – Appliances</b> .....	<b>74</b>
<b>Safety—Read Before Operating</b> .....	<b>74</b>
Furnace.....	75
Thermostat.....	75
Operating Instructions.....	76
External Vents.....	77
Ducting.....	77
Drop-In Cook Top Operation.....	78
Operating Instructions.....	78
Water Heater.....	80
Operating Instructions: Gas.....	80
Operating Instructions: Direct Spark Ignition.....	80
Operating Instructions: Electric Element.....	80
To Turn Off Water Heater.....	83
Winterizing Your Water Heater.....	83
Refrigerator.....	83
Leveling.....	83
Operation During Travel.....	84
Venting.....	84
Moisture Reduction Heater.....	84
Door Sealing.....	84
Door Handles.....	85
Refrigerator Storage.....	85
Operating the Refrigerator Controls.....	85
Air Conditioner.....	86
Monitor Panel.....	86
Outside Kitchen.....	87
Backup Camera.....	88
Solar Panel Receptacle.....	88
Important Phone Numbers.....	88

## CHAPTER 1 INTRODUCTION TO RV OWNERSHIP

Welcome to the growing family of new VENTURE RV owners and the world of recreational vehicle travel. The purchase of your VENTURE RV product allows you to enter this type of camping and leisure travel. Your coach has been designed and engineered to offer many comforts of home. VENTURE Recreational Vehicles are designed and constructed to be used as temporary living quarters for camping and travel uses. The coaches are not intended for hauling cargo.

This owner's manual was prepared to assist you in understanding the proper use and operation of various containment systems, servicing and maintenance of component parts, and explanation of your warranty protection. If this is your first RV travel coach, you will want to acquaint yourself with all aspects and information found in this manual plus manuals supplied by component manufacturers.

These materials will reflect the most current information available for the user. Some components and items may not be in your coach as they may be options on different models.

Keep this owner's manual in your recreational vehicle for handy reference. Get to know your new vehicle and how it operates. You should carefully read and understand these instructions, as well as information supplied by the manufacturers of separately warranted products, since they contain important operating, safety, and maintenance instructions. If you have questions that are not adequately answered by this manual or other booklets, consult your dealer. If he cannot satisfactorily answer your questions, he will call our staff for additional information.

Every effort has been made to provide you with a safe, dependable product. Your vehicle complies with applicable requirements of Federal Motor Vehicle Safety Standards, State Regulations, Canadian Standards Associations (CSA) where applicable, and complies with requirements of ANSI Standard 1192, the nationally recognized "Standard for Recreational Vehicles – Installation of Plumbing, Heating and Electrical Systems." The Recreational Vehicle Industry Association (RVIA) and Canadian Standards Association (CSA) periodically inspect our production lines and assist us in maintaining strict compliance with installation and safety standards for those systems. **Your follow-up with periodic safety inspections and a program of preventive maintenance is important for the continuation of safe and trouble-free operation.**



Camping is a great way to relax and enjoy the outdoors with your friends and family. Please remember to tread lightly on our beautiful land and leave only your footprints so that others may enjoy nature as much as you did.

## **SAFETY CONSIDERATIONS**

The terms **NOTE**, **CAUTION**, **WARNING**, and **DANGER** have specific meanings in this manual as well as component manuals.

A **NOTE** provides additional information to make a step or procedure easier or clearer. Disregarding a **NOTE** could cause inconvenience, but would not be likely to cause damage or personal injury.

A **CAUTION** emphasizes areas where equipment damage could result. Disregarding a **CAUTION** could cause permanent mechanical damage. However, personal injury is unlikely.

A **WARNING** is giving notice to user that potential injuries may occur to a person from equipment and mechanical failure. Disregarding a **Warning** may result in serious physical injury to occupant.

A **DANGER** alerts areas where safety measures **MUST** be strictly adhered to, as such failures can be dangerous. Disregarding a **Danger could** causing serious injury and possible loss of life.

### **Reporting Safety Defects**

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying VENTURE RV.

If NHTSA in addition receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer or VENTURE RV.

To contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-800-424-9393 or write to:

**NHTSA**  
US Department of Transportation  
Washington, DC 20590

You can also obtain other information about motor vehicle safety from the Hotline.

### **Safety When Emergency Stopping**

It is wise to carry road flags and/or triangular warning devices to be used when necessary. When pulling off a highway, use your four way hazard lights as warning flashers, even if only to change drivers. Pull off the road way completely if at all possible to change flat tires or any other emergency needs.

### **Additional Safety Considerations**

1. Sanitize the fresh water supply system periodically (see sanitizing instructions).
2. Keep water connection fittings from coming in contact with the ground or drain hose to reduce chance of contamination.
3. Enlist services of a Qualified RV Technician to fix propane or electrical appliances, or any other gas or electrical system problem.
4. Always have a serviceable fire extinguisher placed in an easily accessible location.
5. Insure that tires are in good condition and properly inflated. Watch tire inflation closely. Under-inflated tires will overheat. Overheated tires are a potential hazard as they may throw rubber and cause a blow-out. Check the tire pressure before each trip while the tires are cold.
6. Check and tighten the wheel lugs regularly (every 50 miles when new until 200 miles are reached and then check the lugs every 500 miles).
7. Check the brakes in a safe area – not while traveling on a busy highway.
8. Always block the trailer wheels solidly before unhitching.
9. Before leaving a camp area with a trailer in tow, insure:
  - a. The safety pin or locking lever is seated.
  - b. The breakaway wire is attached to the tow vehicle.
  - c. All jacks are raised so that they cannot touch the ground.
  - d. The 110-volt electrical cord is properly stored.

- e. The safety chains are connected.
  - f. All interior lights are off.
10. Observe and obey the warning labels attached to your vehicle concerning propane, water, electricity and loading.
  11. Extinguish all campfires before leaving your campsite.

### **EXTENDED OR COLD WEATHER USE**

Your VENTURE recreational vehicle has been built for enjoyment in a recreational manner. This recreational vehicle is not intended to be used as full-time living quarters. Nor is this a four season unit. Using this unit in freezing conditions is not recommended. However, if unit is used in freezing weather, following are guidelines to follow. Any problems resulting from freezing are not covered under warranty.

1. For winter use in freezing conditions, more protection may be required. Use skirting and/or insulation below floor level to provide additional protection.
2. Remember, water freezes at 32° Fahrenheit whether fresh or drainage. Proper care must be used to protect any system at 32° Fahrenheit or lower. Local recreational vehicle dealers and campground personnel may be able to advise you on needed protection.
3. Energy requirements, such as propane and electrical supplies must be adequate. Protect your propane regulator from freeze-ups.
4. During cold weather you will experience more condensation than normal. Using ventilation or a dehumidifier may be needed.

### **CONDENSATION**

Where it comes from, what causes it, and various solutions. Condensation is not a warranty issue.

#### **Causes:**

- A. When cooking food or taking a shower, warm moist air circulates throughout the coach attaching itself to cooler surfaces, forming beads and running down wall or window

- B. Normal breathing will emit approximately 1/2 pint of moisture into the air per person, per day. The more occupants the greater quantity of condensation you may find.

**Solutions:**

1. When taking a shower, open bath roof vent approximately ½ inch allowing moisture to escape.
2. Use the power vent over range when cooking.
3. If condensation is found in cabinet or closets, open door slightly to equalize temperature and provide ventilation.
4. Opening windows and roof vents, when possible, allowing warm moist air to escape is the best way to reduce condensation.
5. Under extreme conditions, you may need to use a dehumidifier to remove moist air conditions.

Uncontrolled condensation can cause dampness, mildew, etc., inside your recreational vehicle. Be sure to make strong efforts to control condensation.



## INTERIOR VENTILATION

A new coach always has a peculiar aroma in it due to all the components used to build it, such as paneling, plywood, carpet and fabrics.

Allowing fresh air to move and circulate throughout a new recreational vehicle is very valuable for several reasons.

1. Components used to build RV's always have a "new" smell to them, possibly irritating the respiratory system of the human body on warm days.
2. Fresh air is always good for the human body unless allergies are a factor.

Numerous ways are provided to exchange air in coaches.

1. Open windows on non-rainy days, allowing air exchange between inside and outside.
2. Power hood vent above cooking stove will send heat and food smell outside.
3. Roof vent; numerous types;
  - a. Standard air flow using gravity flow method.
  - b. Power ( 12v or 110v ) vents will move air faster.
  - c. Hi-volume power vents, operation in 12 volt power can exchange air in a coach in several minutes if windows are open accordingly. If there is a fan in the rear, open window (s) in front.

Different brands/models have different features, such as remote control, rain sensor, variable speed control switch, etc.

Read carefully the operating instructions which are provided by the manufacture and can be found in your coach.

## CHAPTER 2 SERVICE PROCEDURES

### **BASIC SERVICE PROCEDURES**

VENTURE RV and Your VENTURE RV Dealer have a strong and dedicated interest in maintaining the highest quality customer relations with its owners. Your satisfaction with your VENTURE recreational vehicle and your VENTURE RV dealer is our primary concern. In addition to producing high quality products, we want to assure our customers of our support with parts and service availability. **Our dealer network is the first choice to serve and supply your needs for your recreational vehicle.** Our authorized dealers will pleasantly assist in providing service maintenance needs plus parts, options, and information concerning your recreational vehicle.

Should you experience a problem with service availability, please follow the steps in the order listed below.

1. Contact your selling dealer's service department for an appointment. Describe to the best of your knowledge the nature of the problem. Please keep appointments to establish a good, workable relationship.
2. Contact the owner or general manager of the dealership should the initial attempt fail with the service department.
3. Contact:  
Customer Relations Department  
VENTURE RV  
0985N 900W  
Shipshewana, IN 46565  
  
Phone: (888) 988 8440  
Hours: (8am-5pm E.S.T.)  
  
E-mail: [venture@venture-rv.com](mailto:venture@venture-rv.com)  
Website: <http://www.venture-rv.com>

Give all the above information as requested along with the serial number of the coach in question. We will make every attempt to resolve your problem.

Please bear in mind that most problems arise from misunderstandings concerning warranty coverage and service. In most instances, you will be referred to the dealer level and your concerns will be resolved with the dealer's facilities and personnel.

### **Dealer**

Your authorized VENTURE RV dealer has performed a PDI (pre-delivery inspection) on your recreational vehicle. Since your dealer is authorized to sell VENTURE RV products, they are also there to supply parts, optional equipment, and provide service repairs, warranty or otherwise as needed.

First choice for warranty repairs is your selling VENTURE RV dealer. Other dealers can be used, however, prior approval is required.

Some recreational vehicle dealers may be authorized service centers for certain manufacturers of products warranted separately, such as appliances. Check with your dealer before contacting anyone else to reduce delays. If the dealer is not an authorized service center for the product in question, he can assist you in obtaining authorized service.

### **Factory**

Service repairs can be performed at the manufacturing facility at Shipshewana, Indiana. Should your VENTURE RV product be in need of major repairs and your dealer recommends factory repairs, please follow the steps listed below for such work.

1. Your dealer **must** make an appointment with service personnel at the factory PRIOR to your arrival.
2. Any freight costs, are the responsibility of the owner as listed in the warranty coverage schedule.

### **Parts**

Stocking of parts varies from dealer to dealer. Any authorized dealer can order any required part to be shipped to their dealership. All parts are obtained through authorized VENTURE RV dealers only.

### **Owner's Responsibility**

When owning and using a recreational vehicle, it is important to perform regular and normal maintenance. This is recommended twice a year, spring and fall, to prevent undesired deterioration of your coach. Weather elements play an important function on sealants and other components requiring normal maintenance.

As an owner and operator, it is your responsibility and obligation to inspect and return your coach to an authorized dealer for repairs as required. Your authorized selling dealer is always your first choice and he certainly has continued interest in your satisfaction. As your manufacturer, we recommend that inspection and service be performed by your selling dealership.

If you are traveling and are unable to locate an authorized VENTURE RV dealer, or an authorized dealer for the component needing service, please call our customer service office at (888)988-8440. Service at a non-authorized dealer MUST have prior authorization. You may be asked to return any mechanical parts that are replaced before reimbursement consideration is made. Unauthorized or improper repairs may void the warranty of that component. Always keep your owner's manual along with a copy of your warranty registration with you when traveling.

### **Seasonal Site**

When placing your unit on a camp site in the spring and returning it in the fall to your home, it's classed as a "seasonal site."

Performing repair work on such a site is not recommended for numerous reasons; available parts, tools, space, weather conditions, etc.

Any service repairs which require a service technician also require the unit to be taken to a service facility, preferably your selling dealer.

Warranty coverage does not include trip or service call costs for such a trip. It is the owners responsibility to provide for such costs.



# **KZRV, LP d/b/a VENTURE RV TOWABLE LIMITED WARRANTY**

## **One Year Limited Warranty**

**SUMMARY OF WARRANTY:** Venture RV warrants that every towable recreational vehicle or truck camper purchased from an authorized Venture RV dealer to the first retail consumer was free from substantial defects in materials and workmanship when it arrived on the dealer's lot, except those exclusions set forth below. Nothing contained herein shall be interpreted as a promise of future performance. The warranty period begins on the date of purchase or the date the unit is first placed in service, whichever is earlier. This Towable Limited Warranty ["TLW"] does not apply to towable recreational vehicles or truck campers purchased from any source other than an authorized Venture RV dealer.

**EXCLUSIONS FROM WARRANTY:** Excluded from coverage under the TLW are: (1) items added, changed, or modified after the unit left the possession of Venture RV; (2) units used for any commercial purpose; (3) units used for full-time residential use or more than occasional recreational use; (4) wear and tear caused by normal usage by the consumer, including but not limited to fading or discoloration of soft goods [e.g., tents, upholstery, drapes, carpet, vinyl, screens, cushions, and mattresses], fading or discoloration of exterior or fiberglass components, tears, punctures, soiling, mildew, mold, and the effects of moisture condensation inside the unit; (5) the effects of alteration, tampering, mishandling, neglect, abuse, misuse, weather, acts of nature, acts of God, or corrosive atmospheres that promote rusting, oxidation, or pitting; (6) minor imperfections that do not interfere or affect the suitability of the unit for its intended use; (7) the effects of consumer's or transferee's failure to perform normal and routine maintenance [e.g., inspections, lubrication, adjustments, tightening of screws and bolts, tightening of lug nuts and wheels, sealing, rotating, cleaning, or other damages resulting from failing to follow the maintenance schedule and procedures in the owners manual; (8) damages resulting from misalignment or adjustments to axles or spindles caused by improper maintenance, modification, loading, unloading, road hazards, road defects, off road travel, or tire failures; (9) damages caused by the negligent or intentional use or misuse of the unit by the consumer or transferee, including but not limited to occurrences while towing the unit; (10) loss or damage caused by a person or business as a result of transporting the unit after sale to the consumer, delivering the unit, or parking the unit; (11) loss or damage to the plumbing system caused by freezing; (12) claims for personal injuries of any type; (13) costs of transportation of the unit for repairs; and (14) components that are warranted separately by another manufacturer [the warranty provided by a component manufacturer is the sole responsibility of that manufacturer, and Venture RV does not warrant those components. Please refer to the warranties issued by the component manufacturers for the terms and conditions of such warranties].

**TO OBTAIN WARRANTY SERVICE:** Warranty service may be performed only at Venture RV, or at Venture RV authorized dealers and service centers. Contact Venture RV for a list of authorized dealers and service centers. **REPAIRS OR REPLACEMENTS BY UNAUTHORIZED DEALERS OR SERVICE CENTERS WILL VOID THIS TLW.** If the consumer believes that a claimed defect is covered by this TLW, contact must be made with VENTURE RV, as described below, or an authorized Venture RV dealer, **WITHIN THE WARRANTY PERIOD.** Sufficient information must be given to attempt to resolve the claimed problem. Should Venture RV determine that repair or replacement is appropriate, the consumer must deliver the unit to the dealer or service center as directed. Delivery shall occur no later than thirty (30) days after the authorization for repair or replacement. Do not deliver your unit to Venture RV, an authorized dealer, or service center without prior authorization. All costs incurred by the consumer for transportation for warranty service shall be the sole responsibility of the consumer. The consumer must contact Venture RV by **CERTIFIED MAIL** with a written description of the claimed warranted defect and the efforts to remedy it. **FAILURE TO SO NOTIFY Venture RV IN THIS REGARD SHALL RENDER THIS TLW VOID AS TO THE CLAIMED DEFECT.** The scheduling of warranty work at an authorized dealer or service center is not controlled by Venture RV and delays may be experienced. Venture RV is not responsible for loss of use of the unit, expenses for fuel, telephone, food, lodging, travel, loss of income or revenue, or loss of or damage to personal property.

**DISCLAIMER AND LIMITATIONS OF WARRANTIES:** NEITHER VENTURE RV, NOR ITS DEALERS SHALL BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND OR ANY OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE OR USE OF THIS PRODUCT, WHETHER BASED IN CONTRACT, TORT, STRICT LIABILITY, EQUITY, OR ANY OTHER THEORY, EVEN IF Venture RV HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Venture RV'S ENTIRE LIABILITY SHALL BE LIMITED TO REPAIR OR REPLACEMENT, AT Venture RV'S SOLE OPTION. THE UNITED NATIONS CONVENTION ON CONTRACTS FOR THE INTERNATIONAL SALE OF GOODS IS HEREBY EXCLUDED IN ITS ENTIRETY FROM APPLICATION TO THIS TLW. THIS TLW, AND THE REMEDIES HEREUNDER, ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, CORRESPONDENCE WITH DESCRIPTION, AND NON-INFRINGEMENT, ALL OF WHICH ARE EXPRESSLY DISCLAIMED BY Venture RV. THIS TLW GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY DEPENDING ON LOCAL LAW. SOME STATES LIMIT OR PROHIBIT LIMITATIONS OF WARRANTIES, SO THE ABOVE MAY NOT APPLY TO YOU. YOU SHOULD CONSULT A COMPETENT ATTORNEY FOR LEGAL ADVICE

**MISCELLANEOUS:** No repair or replacement effected shall cause any extension or renewal of the warranty period. Venture RV may make parts and/or design changes from time to time without notice and repairs or replacements may be made with new or different parts. Venture RV reserves the right to make changes in the design or material of its products without incurring any obligation to incorporate such changes in any product previously manufactured. At Venture RV's, sole option, any dispute concerning any warranted defect may be resolved through mediation or arbitration. This TLW shall be governed by the laws of the State of Indiana, and any legal action shall be brought only in the Circuit or Superior Court of LaGrange County, Indiana. In case of conflicts between this TLW and any other warranties issued or conveyed by Venture RV, the terms of this TLW shall govern.

**ALTERNATIVE DISPUTE RESOLUTION:** The parties shall attempt in good faith to resolve any disputes by negotiations. If unsuccessful, Venture RV may, in its sole discretion, elect to submit the matter to binding arbitration and, if such election is exercised, the consumer covenants and agrees that he, she, they, or it shall submit any such disputes to such binding arbitration. The arbitral body shall be either the American Arbitration Association or the National Arbitration Foundation, and the rules of the body chosen by Venture RV shall govern except to the extent same are in conflict with the Indiana Uniform Arbitration Act, which shall govern. The arbitrator is expressly empowered to enter an award of default against any party in the event of: (a) the failure or refusal of such party to comply with any deadline fixed by the arbitrator; (b) the failure or refusal of such party to make timely payment of any fees, expenses, or other charges billed by the arbitrator; or (c) any other failure or refusal by such party to cooperate and participate in any aspect of the arbitration proceedings. The arbitrator will admit only relevant and reliable evidence at the hearing, but no particular rules of evidence are specified for use. The hearing shall be electronically recorded by an Indiana Notary Public or other officer authorized by Indiana law to administer oaths, and all witnesses who shall testify shall be sworn on oath to tell the truth. The arbitrator may award injunctive relief, interest, and attorney fees in an equitable amount based upon the degree to which the prevailing party prevails on the merits; however, the arbitrator is not empowered to award punitive or exemplary damages. All costs of the arbitration, including the recording thereof, shall be shared equally by the parties. The arbitration proceedings and award shall remain confidential, and no party may disclose to any person, except attorneys for the parties, any aspect of the proceedings.

**WARRANTY REGISTRATION AND CONTACT INFORMATION:**

The warranty registrations for component parts should be completed and delivered in accordance with the instructions contained therein. The TLW registration must be completed and returned to Venture RV within fifteen (15) days of delivery of the unit to the consumer. Failure to do so can void this TLW or cause delays in obtaining benefits. The TLW registration, and all inquiries, must be directed to: VENTURE RV, Warranty Department, 0985N 900W, Shipshewana, Indiana 46565, Telephone: (260) 768-4016. [Form 1 year 6-1-12]

*Model Number* \_\_\_\_\_ *V.I.N.* \_\_\_\_\_

*Dealer Information:*

[ \_\_\_\_\_ ]

*Customer Information:*

*Name:* \_\_\_\_\_

*Address:* \_\_\_\_\_

\_\_\_\_\_

*Phone:* \_\_\_\_\_

***I HEREBY ACKNOWLEDGE THAT I HAVE RECEIVED, READ, AND UNDERSTAND THIS TOWABLE LIMITED WARRANTY, AND THAT I HAVE INSPECTED THE UNIT AND FIND IT IN THE CONDITION REPRESENTED.***

Date: \_\_\_\_\_

\_\_\_\_\_  
Purchaser

## **CHAPTER 3 USING YOUR RV**

In this chapter you will find three areas of useful information to assist you with correct **equipment**, **traveling**, and finally, actually **using your recreational vehicle**.

### **EQUIPMENT**

---

#### **Tow Vehicle**

Begin your camping experiences by obtaining a tow vehicle which will adequately transport your recreational vehicle to and from your chosen destinations. Your most important measuring tool is the GVWR, Gross Vehicle Weight Rating, to cross match the capability of your selected tow vehicle.

Most auto and truck manufactures provide trailer towing guides for their products. Ask your local automotive dealer for a copy or call the factory's direct lines for information. Many tow vehicles, including mini-vans, have special towing package options available for small travel trailers. Tow vehicles with long wheel bases perform better than those with short wheel bases.

A second factor is GCWR, Gross Combined Weight Rating, which refers to the total weight of the tow vehicle and any vehicle in tow as a "combined" weight. This information, supplied by the tow vehicle manufacturer, is related to the capability of the tow vehicle.

The condition of the suspension in your tow vehicle is also an important factor. Make sure your tow vehicle is in good operating condition and follow the factory recommended maintenance guidelines.


#### **Hitches – Travel Trailer**

After obtaining your tow vehicle, it is very important to choose, and have installed, a correct hitch system with weight distributing bars to accommodate your coach if so required. This selection and installation should be done by a professional hitch service center, which may or may not be your selling dealer.

Weight distributing hitches apply leverage between the tow vehicle and trailer. This assists in equalizing the weight between vehicles, resulting


in both vehicles traveling level. The condition of the tow vehicle's suspension system will affect the towing performance capability of your equipment.

Sway controls may be needed based on size and weight of coach, plus capability of your tow vehicle.



### Hitch Height Specifications – Travel Trailer

Due to axles being either straight or drop bar, the ball height will vary. To find the correct height for the ball hitch, set your trailer on a flat AND LEVEL surface in level position. Measure from the inside of the ball socket to the ground, approximately 18 to 22 inches as shown, for correct spacing. You may wish to add 1 to 2 inches. to this amount to compensate for sag of suspension of the tow vehicles when hooked to tow vehicles.



### Hook-Up (Travel Trailer)

Hooking up your travel trailer is not difficult and gets easier with practice. The following procedure will help you until you become more experienced.

1. To raise the tongue of trailer above the hitch ball on hitch, turn the crank on the jack.
2. Open the coupler latch.

3. Back the tow vehicle into proper position, coupler over ball.
4. Turn the crank on the jack to lower the coupler onto the ball hitch.
5. Close the coupler latch after completely seated and insert pin.
6. Install weight distributing bars (equalizer), when required, as recommended by hitch supplier.
7. Retract the tongue jack to its maximum height.
8. Attach the cable for the breakaway switch to the tow vehicle.
9. Attach safety chains as per your state laws.
10. Plug in your 12-volt, seven way electrical connector from the tow vehicle to the trailer connector.
11. Below are listed numerous items that should be inspected and tested before traveling:
  - q All lights working on outside of coach.
  - q Stabilizer jacks in retracted position.
  - q Steps in retracted position.
  - q Refrigerator door latched completely.
  - q Loose items in secure position.
  - q Test brakes for operation BEFORE entering roadway.

#### **The Safety Chain (Travel Trailer)**

Safety chain requirements will vary from state to state. The chain supplied with your coach meets SAE requirements for maximum gross trailer weight.

1. Cross the left chain under the coupler and attach to the to the right ring on hitch receiver.
2. Now take the right chain under coupler and attach to the left ring on hitch receiver.



## **TRAVELING**

---

### **Weights**

For safety reasons and federal regulations VENTURE RV provides accurate weight specifications to owners. On the exterior left front corner of the coach you will find the Federal "Vehicle Identification Number" sticker, as required by the federal government. This tag supplies information concerning your coach, such as: VIN number, date/month of manufacture, tire size rating, plus information about weights as described below.

---

MANUFACTURED/FABRIQUE KZRV.                      DATE  
GVWR/PNBV;    SHIPSHEWANA,IN.  
GAWR/PNBE;  
WHEEL/JANTE;  
COLD INFL. PRESS./ PRESS DE GCNFL. A FROID  
THIS VEHICLE CONFORMS TO ALL APPLICABLE U.S. FEDERAL  
MOTOR VEHICLE SAFETY STANDARDS IN EFFECT ON THE DATE OF  
MANUFACTURE SHOWN ABOVE.

VIN/NIV NUMBER.

---

Gross Axle Weight Rating (GAWR), is the value specified as the load carrying capacity of a single axle system, as measured at the tire-ground interfaces. Effective September 2017, the tires will be rated 10% higher than the axle, becoming the rating for GAWR.

Gross Vehicle Weight Rating (GVWR), is the maximum permissible weight of this trailer when fully loaded. It includes all weight at the trailer axle (s) and tongue. This includes ALL cargo, options and liquids.

Unloaded Vehicle Weight (UVW), is the weight of this trailer as manufactured at the factory. It includes all weight at the trailer axle(s) and tongue. If applicable, it also includes full generator fluids, including fuel, engine oil and coolants.

Cargo Carrying Capacity (CCC), is equal to the GVWR minus each of the following, UVW, full fresh (potable) water weight (including water heater, and full propane weight.



### Weighing Vehicle (Loaded or Unloaded)

The proper method to weigh the coach is to use a truck scale. Place the coach axles (tires) and tongue jack, 12" to 24" from the edge. Unhook the tow vehicle and move forward 6" to 8". Now record total weight. Re-hook the tow vehicle. Be sure no part of tow vehicle is on the scale. Now record the axle weight only. The difference between the two weights is the hitch weight.

VENTURE RV suggests you also weigh each side (2 tires) separate to find balance of pounds per side. Its possible to have 1 side correct and the other side over-loaded. Often the slide out side or refrigerator side will be slightly heavier than the other.

The **second sticker** is about the weight of cargo placed in your coach. Location is on the inside of your coach, on the screen door, or inside of a cabinet door. It provides listed total allowable weight of cargo minus liquids allowed, water and propane.

---

#### RECREATIONAL VEHICLE TRAILER CARGO

VIN \_\_\_\_\_

The weight of cargo should never exceed

Kg. \_\_\_\_\_ Lbs.

#### CAUTION

A load of water equals \_\_\_\_\_kg, or \_\_\_\_\_lbs. of cargo @

**Kg or 8.3 lbs. per gallon.**

---

### Loading the Trailer—Distribution

Your recreational vehicle has been engineered to make maximum use of the available space for living and storage areas. The equipment and supplies you take along while traveling can be carried safely, provided the additional weight is distributed properly. Proper weight distribution within your trailer is an important factor in safety and efficiency of your trailer brakes, hitching, and how your tow vehicle will pull the trailer. **DO NOT** put excess weight in the rear only. Excessive weight in the rear area tends to develop sway and "fishtailing" of the trailer.

Lightweight and bulky items such as paper products, bedding, clothing, etc., should be stored in overhead cabinets and closets. Heavy items

such as cooking utensils should be placed in lower cabinets. Canned goods need to be in a pantry, if so equipped, or in lower cabinets. Also, heavy items should be secured to avoid shifting during travel.


A reasonable principle in loading your coach is for every two pounds of weight loaded in front of the axle, one pound of weight must be loaded behind the axle. Also remember, improper side-to-side loading affects spring condition.

Excess weight behind the axle lightens the hitch weight and will tend to magnify any sway that may occur when passing trucks or when gusty winds are present. Uncalculated weight can and will effect road performance.

When using a weight distributing hitch and equalizer bars, you may move/transfer hitch weight from coach to tow vehicle assisting with level towing and easier travel.



Below is a blank space for you to calculate the " Cargo Carry Capacity " of your unit. You will find the weights of your unit on a sticker, placed on the edge OR CENTER of the screen door. This will enable you to determine your " Cargo Carry Capacity " in the different areas of your unit.



## WARNING

The rear bumper on the frame will only carry 100lbs, therefore only the spare tire carrier, and spare tire can be added to the bumper. Do not add any other components to the bumper, such as bike racks, generators, cargo containers, and etc. Such items could cause fatigue and weld stress, which is not covered under warranty. Any such failures could damage your property and endanger vehicles following your camper during travel, which could result in an accident.

This frame is NOT designed or built to tow any trailer.

### **Towing**

When towing your trailer you need to recognize the extra weight behind your vehicle. Below is a list of things which you need to remember while traveling.

1. With the trailer attached you will have slower acceleration and will require more distance to stop.
2. Be sure you have enough area at corners when turning, as wider turns are necessary. Be sure to use your turn signals for your own safety and the safety of others.
3. In passing or changing lanes remember you will need a longer distance to pass.
4. Use your rearview mirrors frequently to observe your trailer and traffic conditions.
5. When being passed by a large truck or bus, be prepared for displaced air as it may cause you to sway slightly, especially travel trailers.
6. When climbing steep, long grades and again while descending, use lower gears even before it seems necessary. Use your brakes smoothly and evenly.
7. Remember to drive more slowly on wet and icy highways to keep control of your vehicle.

### **Tires**

All VENTURE RV towable coaches are equipped with appropriate tires for recreational vehicles. Tires are rated to carry weight as listed to G.V.W.R.

Tires are radial in design using components to offer excellent strength and mileage in all kinds of weather conditions.

Tires on your vehicle( s) are one of the most important components of the towing package. Without inflated tires, you will not be moving anywhere.

Taking care of your tires during travel is very important. Top of the list is maintaining correct air pressure and secondly is NOT over loading your RV.

With proper care, the performance of fuel economy and handling on the road will be better.

Safety on the road is very important in avoiding road hazards which can damage your tires plus obeying the speed limit.

On the left front, exterior corner of your coach, you will find the (VIN) label along with a placard as shown below, supplying information on tires such as tire size and amount of air pressure (maximum).

Both placards and certification labels are permanently attached to the trailer on the left front corner of exterior and easily readable from the outside of the vehicle without moving any covers.

Due to weather elements, labels may fade over time. You may wish to record this information and keep it on the inside of coach, perhaps with owner's manual.


---

TIRE	SIZE	..... COLD TIRE PRESSURE
PNEU	DIMENSIONS	.....PRESSIONDES
		PNEUS A FROID
FRONT		
AVANT		
REAR		
ARRIERE		
SPARE		
DESESCOURS		

---

### **Safety First-Basic Tire Maintenance**

Properly maintained tires improve the steering, stopping, traction, and load carrying capability of your vehicle. **Under inflated tires and overloaded vehicles are a major cause of tire failure.**



### **Understanding Tire Pressure and Load Limits**

Tire inflation pressure is the level of air in the tire that provides it with load-carrying capacity and affects the overall performance of the vehicle. The tire inflation pressure is a number that indicates the amount of air pressure as measured in pounds per square inch (psi) - a tire requires to be properly inflated. (You will also find this number on the vehicle information placard expressed in kilopascals (kPa), which is the metric measure used internationally.)

The listed amount of air pressure is for maximum load capacity. When traveling with less than full weight, you may wish to reduce air pressure slightly for smoother ride.

While driving your tires will get warmer, causing air pressure to raise. To get an accurate pressure reading, you must allow tires to cool for at least 3 hours.

For convenience, purchase a good quality pressure gauge to keep in your tow vehicle. Gauges can be purchased at auto parts store.

Because tires are designed to be used on more than one type of vehicle, tire manufacturers list the "maximum permissible inflation pressure" on the tire sidewall. This number is the greatest amount of air pressure that should ever be put in the tire under normal driving conditions.

### **Tire Size**

To maintain tire safety, purchase replacement tires that are the same size as the vehicle's original tires or another size recommended by the manufacturer. Look at the tire information placards, or the sidewall of the tire you are replacing to find this information. If you have any doubt about the correct size to choose, consult with the tire dealer.

### **Tire Tread**

The tire tread provides the gripping action and traction that prevent your vehicle from slipping or sliding, especially when the road is wet or icy. In general, tires are not safe and should be replaced when the tread is worn down to 1/16 of an inch. Tires have built-in tread wear indicators that let you know when it is time to replace your tires. These indicators are raised sections spaced intermittently in the bottom of the tread grooves. When they appear “even” with the outside of the tread, it is time to replace your tires.

### **Tire Balance and Wheel Alignment**

Tires are not balanced on your unit, nor is it required. You may choose to balance the tires on your unit, however this will not be covered under warranty.

Wheel alignments may be needed periodically due to road hazards, such as pot holes, etc. This also is not covered under warranty, due to being a uncontrollable element. Wheel alignments, will assist with getting the maximum life from your tires. Alignments require special equipment, and should be performed by a qualified technician.

### **Tire Repair**

The proper repair of a punctured tire requires a plug for the hole and a patch for the area inside the tire that surrounds the puncture hole. Punctures through the tread can be repaired if they are not too large, but punctures to the sidewall should not be repaired. Tires must be removed from the rim to be properly inspected before being plugged and patched.

### **Tire Fundamentals**

Federal law requires tire manufacturers to place standardized information on the sidewall of all tires. This information identifies and describes the fundamental characteristics of the tire and also provides a tire identification number for safety standard certification and in case of a recall.

Considerable quantity of information is built in to the side wall of a tire, such as, date of manufacture, size, weight limit tire can carry, air pressure, serial number, and where it was built.

The letters “ST” refer as “service trailer” meaning they are for RV TRAILERS, manufactured for that purpose. These tires should not be used for automotive use.

NOTE; Each original tire installed on KZ –RV recreational vehicles have a speed rating of 75 mph, or greater. Please note maximum load rating, tire pressure, and speed rating as imprinted on the sidewall of tire.

**Effective** in 2017 model year, your tires will have NITROGEN in them instead of air. Green caps on the valve stems indicate contents as nitrogen. Air may be used if nitrogen is not available.

### **Vehicle Load Limits**

Determining the load limits of a vehicle includes more than understanding the load limits of the tires alone.

On a trailer, there is a Federal certification label that is located on the forward half of the left (road) side of the unit, called ‘VIN’, which is the vehicle identification number.

The certification label will indicate the vehicle’s gross vehicle weight rating (GVWR). This is the most weight the fully loaded vehicle can weigh. It will also provide the gross axle weight rating (GAWR). This is the most weight a particular axle can carry. If there are multiple axles, the GAWR of each axle will be provided.

In the same location as the certification label described previous, there is a vehicle placard. This placard provides tire and loading information. In addition, this placard will show a statement regarding maximum cargo capacity.

### **Cargo Capacities**

Cargo can be added to the vehicle, up to the maximum weight specified on the placard. The combined weight of the cargo is provided as a single number. In any case, remember: the total weight of a fully loaded vehicle can not exceed the stated GVWR.

Water and propane also need to be considered. The weight of fully filled propane containers is considered part of the weight of the RV before it is loaded with cargo and is not considered part of the disposable cargo load. Water however, is a cargo weight and is treated as such. If there is a

fresh water storage tank of 100 gallons, this tank when filled would weigh about 800 pounds. If more cargo is being transported, water can be off-loaded to keep the total amount of cargo added to the vehicle within the limits of the GVWR so as not to overload the vehicle. Understanding this flexibility will allow you, the owner, to make choices that fit your travel and camping needs.

When loading your cargo, be sure it is distributed evenly to prevent overloading front to back and side to side. Heavy items should be placed low and as close to the axle positions as reasonable. Too many items on one side may overload a tire. The best way to know the actual weight of the vehicle is to weigh it at a public scale. Talk to your RV dealer to discuss the weighing methods needed to capture the various weights related to the RV. This would include weights for the following: axles, wheels, hitch, and total weight.

### **How Overloading Affects Your RV and Tires**

The results of overloading can have serious consequences for passenger safety. Too much weight on your vehicle's suspension system can cause spring, shock absorber, or brake failure, handling or steering problems, irregular tire wear, tire failure or other damage.

An overloaded vehicle is hard to drive and hard to stop. In cases of serious overloading, brakes can fail completely, particularly on steep hills. The load a tire will carry safely is a combination of the size of tire, its load range, and corresponding inflation pressure.

Excessive loads and/or under inflation cause tire overloading and, as a result, abnormal tire flexing occurs. This situation can generate an excessive amount of heat within the tire. Excessive heat may lead to tire failure.

It is the air pressure that enables a tire to support the load, so proper inflation is critical. Since RVs can be configured and loaded in many ways, air pressures must be determined from actual loads (determined by weighing) and taken from the load and inflation tables provided by the tire manufacturer. These air pressures may differ from those found on the certification label. However, they should never exceed the tire limitation for load or air pressure. If you discover that your tires cannot support the actual weights, the load will need to be lightened.

**Note:** Tires are warranted by the manufacturer of their respective brand and are to be serviced and warranted by a service center. Contact your dealer for information on service centers for tires.



## How to Change a Tire

1. Place blocking under main rail/frame with hydraulic jack on top of blocking in front of spring hanger, ALWAYS on main rail.
2. Break lug nuts loose before raising coach. DO NOT remove nuts.
3. Raise coach with jack until tire is off the ground.
4. Place additional blocking under frame for security support. DO NOT depend fully on jack.
5. Be sure coach is solid and will not move with tire and wheel off.
6. Remove lug nuts when tire is off the ground.
7. Install spare tire and wheel onto hub.
8. Reinstall lug nuts and tighten firmly.
9. Drop tire and wheel onto ground after removing supports.
10. Now fully tighten and torque lugs at 90 to 120 foot pounds.
11. Place all equipment into coach or tow vehicle, blocking and jack.
12. Re-torque wheel after traveling 100 miles.

## Wheel Bearings

ALL wheel bearings are pre-lubricated during assembly of axle and brakes. Your coach may have 'ULTRA LUBE' method of having a grease fitting in the end of axle. Remove rubber cap on end and use standard grease gun to place 6 TO 8 shots of grease into bearings. Don't forget to repack your bearings correctly as per maintenance manual.

## Wheel Lugs

When the wheels are installed on your recreational vehicle, the lug nuts must be tightened at 90-120 foot pounds of torque. Powder coat painted wheels may require more torque attempts due to thickness of paint. You must re-torque the wheel lugs at 50 and 200 miles when new. A decal on the wheel may require torque earlier.

After your first trip, check the wheel lugs periodically for safety. The wheel lugs should then be checked after winter storage, before starting a trip or following extensive braking. The size of bolts or nuts is 13/16 inch standard and 3/4" for chrome nut. **Over torque will damage components, especially if torque wheel lugs goes over 150 pounds. Normally the "nut" fails first however the embossing on the wheel can also be flattened, and then fail to keep wheel tight.**

## **Brakes – Electrical**

Electric brakes on your recreational vehicle are designed to work in conjunction with the hydraulic brakes on your tow vehicle. This means to have the best brake performance on both systems, the trailer and the tow vehicle must perform and operate together. Any attempt to use either brake system alone, tow vehicle or trailer will cause accelerated wear and damage.

A brake control is required to be installed under dash of tow vehicle to operate brake system, using 12 volt DC power. Electronic type is used most widely. Each brand has their own operating instructions.

Battery in the tow vehicle is your primary source of power to operate the brake system in towable trailer. Keep battery and charging system in good working condition to ensure available energy when needed.

Wiring to operate your brakes must be sized correctly in both vehicles, suggesting a minimum of 14 gauge from tow vehicle to trailer brake assemblies. Wiring is done parallel, never in series. Being parallel, there will be equal voltage at each brake assembly for equal braking capability and performance.

Use the foot pedal control for general operation on combined use of both brake systems. Manual control is to be used only in special situations, such as slow movement or icy road conditions. In open position, electrical current will flow to brake assemblies activating them.

When applying brakes to stop the trailer, begin pressing slowly to avoid quick and sudden stops, or possible “jack-knife” when wet or slippery. Use lower gear ranges to minimize the need of brakes during extended or steep downgrades.

Your coach has self-adjusting brake assemblies that will correct any looseness in operation as they will adjust in forward or backward motion as soon as pulling begins.

## **Breakaway Switch**

The breakaway switch is a safety part of your trailer's electric brake system. The very instant a breakaway occurs, the pull pin which is linked to the tow vehicle is pulled from the switch. The two contacts automatically close to complete the electrical circuit and apply the trailer


brakes. This system will apply the brakes of the trailer should it become loose or detached from the tow vehicle. A 12-volt battery installed on the coach is required to power the breakaway switch.

**Never** use this breakaway switch and trailer brake system as a parking brake. There would be a high amp draw on battery and converter, potentially causing damaged wiring, connectors, and breakaway switch plus unnecessary energy draw. When plunger is pulled with power engaged there is a constant 12 volt draw on energy source to the brake assembly.

**CAUTION;** REMOVING PLUNGER WITH POWER TO BRAKES COULD RESULT IN DAMAGE TO BRAKES.

**WARNING;** Removing plunger while in storage could result in corrosion of unit points.

**WARNING;**A tag may be attached to lanyard cable: DO NOT use as a parking brake.



**SAFETY BREAK-AWAY SWITCH  
WILL NOT OPERATE**

Unless connected to a power source equivalent to or greater than an auto-motive type 12 volt, 12 amp hour wet-cell battery.

**SETTING UP AND USING YOUR RECREATIONAL VEHICLE**

We recommend that you select a level or nearly level place for camping. There are two reasons to be level. First, all components in your coach, such as your water drainage system and especially your refrigerator, are designed to operate in a level position. Second, it is more comfortable to

live on the level. Should a level site not be available, use short 2 x 6 inch blocks of wood to raise the low side wheels to a level position.

Before unhooking the trailer from the tow vehicle, be sure the jack foot is in place on the tongue jack and block the trailer wheels to keep the trailer from moving.

Before lowering the tongue jack, you may wish to place a wood block or hard support under the foot of the jack, unless you are on a cement slab. This helps to prevent the jack from sinking onto the dirt.

### **Travel Trailer Hook Up**

1. Release the weight distributing bars (if used).
2. Release the safety latch on the coupler.
3. Raise the coupler on the A-frame by turning the tongue jack until the ball is free.
4. Disconnect the 7-way wire connector, safety chains, and the breakaway cable.
5. Raise front jack until Tow vehicle will clear coupler. Drive Tow vehicle away.
6. Now raise/lower front end until coach is level.
7. Lower stabilizer jacks to desired position to stabilize coach.
8. Reverse procedure to hook up coach to tow vehicle.

The use of stabilizer jacks on a recreational vehicle is a popular and useful option. They provide a reasonable amount of stability while using, occupying, and moving around in your camper. It is important to remember that stabilizer jacks are for support of the coach and are not designed to bear the weight of a recreational vehicle.

To operate the stabilizer jack, place crank onto the jack shaft and turn clockwise to lower until the frame begins to raise slightly. Equalize all four jacks for best support. You may need to adjust each jack two or three times.


To raise jack to upper travel position, insert crank and turn counterclockwise until jack is seated in UP travel position.

Upon completing the setup of your coach, you are now ready to make attachments to various facilities:

- ✓ Waste water hose connections.
- ✓ 110-Volt power cord electrical hookup.

- ✓ Turn on propane tanks and light pilot lights, if any, on appliances. Remember there may be air in your propane lines. Be sure to bleed them before planned usage.
- ✓ Open any windows and roof vents as desired for ventilation.
- ✓ Fresh water connections.

You may have additional accessories and options, such as an awning on the door side which need to be opened. Separate instructions are provided by the manufacturer of these components.



### **GENERAL DETECTOR INFORMATION**

As you are confined in a RV which is much smaller than a standard house, you must realize safety detectors will be activated much sooner than in a residential house, due to there being much less air volume.

**TEST ALL SAFETY ALARM OPERATION AFTER VEHICLE HAS BEEN IN STORAGE, BEFORE EACH TRIP, AND AT LEAST ONCE PER WEEK DURING USE.**

Each listed detectors has it's own manual and instructions sheet, providing more information for it's use and maintenance. Life time of each detector ranges from five to ten years and will need to be replaced as per manufactures instructions.

### **SAFETY DETECTORS—3**

#### **Fire Extinguisher—#1**

Fire extinguisher is installed in each vehicle and is located near the entrance door in the RV. Be familiar with it's location and operating instructions as printed on the extinguisher. Inspect your fire extinguisher at least twice per year or more, as instructed on the extinguisher.

## **Propane/Carbon Monoxide Detector —#2**

Any recreational vehicle which contains a propane fuel system with propane consuming appliances requires a propane leak detection device for safety protection. Currently this detector also serves as a carbon monoxide protection device. A converter or auxiliary battery is required to supply 12-volt DC energy to operate the device. There is no master cut-off switch to disengage detector.

### **WHAT IS CARBON MONOXIDE?**

Carbon Monoxide (CO) is a highly poisonous gas which is released when fuels are burnt. It is invisible, has no smell and is therefore very difficult to detect with the human senses. Under normal conditions, in a room where fuel burning appliances are well maintained and correctly ventilated, the amount of carbon monoxide released into the room by appliances is not dangerous. These fuels include: wood, coal, charcoal, oil, natural gas, gasoline, kerosene, and propane. Such gases can build up in the blood, interfering with the body's ability to supply oxygen to itself.

Because CO is a colorless, odorless, tasteless, and highly poisonous gas that prevents the blood from carrying oxygen to vital organs, CO is 200 times more likely to replace oxygen in the blood. It can endanger lives even at low levels of concentration.

### **DUAL SENSOR TECHNOLOGY**

The SAFE-T-ALERT 35 series combination CO/Propane Gas Alarm is an alarm that combines into a single, compact system a powerful alarm that detects both Carbon Monoxide (CO) and explosive gases propane.

The 35 series uses the latest microprocessor technology combined with two electronic self-cleaning sensors that operate independently of each other. The combined unit can detect CO and explosive gases simultaneously.

### **OPERATION**

When the unit is first powered up, the CO sensor requires a ten (10) minute initial warm-up period to clean the sensor element and achieve stabilization. The GREEN LED indicator will flash on and off during the 10 minute warm-up period. The unit cannot go into a CO alarm during the warm-up period. To test your unit during the warm-up period, press

the test button. See Test Procedure in this manual. After the warm-up period, the GREEN power ON indicator should glow continuously. If the ON indicator light does not light, see the section, **Trouble-Shooting Guide**, in the user's manual for further information. **Do not attempt to fix it yourself.**

**Gas Alarm:** When you power the alarm, it has a warm-up period of approximately 1 minute. This unit cannot go into a gas alarm during the warm-up period. After 1 minute the alarm can detect explosive gas and will energize the relay on models 35-742-R and 35-742-R-MS.

**Simultaneous CO and Gas Alarms—** Because the risk of a propane gas explosion is generally a more serious danger, your alarm unit gives the gas alarm a higher priority during simultaneous alarm condition. If your unit generates alarms for both Gas and CO at the same time, the gas LED will flash red and the beeper will sound. The CO LED will be a solid Red until the CO is ventilated out of the RV, at which time the LED will return to the Green operational/safe color.

**Brownout Protection—** The unit can tolerate short power interruptions and brownouts where the circuit voltage drops as low as 1 VDC. If the brownout lasts too long, the unit will reset and operate as described above.

#### **LOW POWER OPERATION**

This alarm will operate normally down to 7 VDC. Do not operate this alarm below 7 VDC.

#### **VISUAL AND AUDIBLE ALARM SIGNALS**

This SAFE-T-ALERT™ CO/Propane Gas Alarm is designed to be easy-to-operate. The alarm has two indicator lights that display a specific color for each monitored condition. There also is a matching sound pattern for alarm conditions.

#### **CO ALARM**

The Red CO LED will flash and the alarm will sound 4 “BEEPS” then be silent for 5 seconds. These signals indicates that the CO level is over 35 ppm. **IMMEDIATE ACTION IS REQUIRED.** See the **Procedures To Take During An Alarm** in the user's manual that is supplied with the detector. This cycle will continue until the TEST/Mute button on the front

of alarm is pressed. Ventilate the RV. The RED light will stay ON until the CO has cleared, or the alarm will reactivate in approximately 6 minutes if the CO is still present. DO NOT RE-ENTER THE RV. This alarm will return to normal operation after the RV's properly ventilated.

**PROPANE GAS ALARM**

The RED LED will flash and the alarm will sound a steady tone whenever a dangerous level of propane or methane gas is detected. **IMMEDIATE ACTION IS REQUIRED.** See **Procedures To Take During A Gas Alarm.** The detector will continue to alarm until the Test/Mute switch on the front of the alarm is pressed. Ventilate the RV. The RED Gas LED will continue to flash until the gas has cleared, or the gas alarm will reactivate in approximately 5 minutes if the gas is still present. DO NOT RE-ENTER THE RV. This alarm will return to normal operation after the RV is properly ventilated.

**MALFUNCTION/SERVICE SIGNAL.** If any malfunction is detected, the Gas LED will remain off and the Operational/CO LED will alternate Red/Green and the alarm will sound once every 15 seconds. Press the Test/Mute button. If the Test/Mute button does not clear signals, check the battery voltage. **If the battery voltage is not low and the unit will not return to normal operation, immediately remove the alarm and return for service or warranty replacement.**


<u>OPERATION SIGNAL</u>	<u>AUDIBLE SIGNAL</u>	<u>VISUAL SIGNAL</u>
NORMAL	NONE	STEADY GREEN
CO ALARM	4"BEEPS" 5 SECONDS OFF	STEADY RED
PROPANE ALARM	CONSTANT	FLASHING RED
ALARM	"BEEP" EVERY	ALTERNATING
MALFUNCTION	30 SECONDS	RED/GREEN
END OF LIFE	BEEP EVERY 30 SECONDS	RED/RED GREEN/GREEN FLASHING

**END OF LIFE SIGNAL**

All 35 series models include an End of Life (EOL) Signal indicating the sensor has the end of it's service life and you MUST replace the alarm.



The signal is the LED flashing RED/RED, GREEN/GREEN with a beep every 25-30 seconds. The EOL signal may be reset by pushing TEST/RESET button on the alarm. This will reset the EOL signal for a period of 72 hours for a total of up to 30 days. After 30 days the signal cannot be reset and the alarm MUST be replaced. DO NOT DISCONNECT THE ALARM UNTIL YOU HAVE A REPLACEMENT ALARM AVAILABLE TO INSTALL.



### **Smoke Alarm—#3**

Smoke alarms are required when propane is used in coach and open flame cooking happens. Alarm is placed on ceiling between bedroom and kitchen.

Energy to operate is supplied by a 9 volt battery inside of alarm.

**Operation:** The smoke alarm is in operation once the battery is correctly connected. The LED will flash every minute to show the battery is supplying power to the alarm. When production of combustion are sensed, the unit sounds a loud alarm which continues until the air is cleared.

Each smoke alarm has its own manual and is normally found in your supplied materials with coach.

### **TESTING**

Test the alarm by pushing the test button on the smoke alarm cover for at least three seconds, until the alarm sounds. The alarm sounds if all


electronic circuitry, horn and battery are working. If no alarm sounds, the unit has a defective battery or other failure and should be replaced immediately.

- Test each smoke alarm weekly to be sure it is installed correctly and operates properly.
- Test smoke alarms after the recreational vehicle has been in storage, before each trip, and at least once a week during use.
- Stand at arm's length from the smoke alarm when testing. The alarm horn is loud to alert you to an emergency. The alarm horn may be harmful to your hearing.
- The test button accurately tests all functions. DO NOT use an open flame.
- Smoke alarm will NOT sound in and around flames—only smoke. Life time on smoke alarm is 10 years.



**STEPS  
(Two or Three)**

Before entering your recreational vehicle place your hand in the center of the step assembly. Pull the step outwards. The step assembly will raise slightly and then out, away from the coach. The lower step will unfold 180° to useable position. The arm on the step will meet a positive stop. Step care, maintenance and lubrication will be found in the maintenance manual.



## **Windows**

All windows are of slider opening design, solid picture window, or opening vent panels. Sliders may open horizontal or vertical as called for per floor plan. Egress windows have an unlocking handle or two small hinged clips on each side. After unlatching, the panel will swing out on a top hinge. On some egress windows, screens are attached to the swing out panel of window.

## **Doors**

Locks on entrance doors have two lock mechanisms, a deadbolt in the frame section of lock and a standard lock in the handle. Both locks use the same key.

Screen doors usually have a hook/lever type of latch. Pull lever downward to release screen door.

Locks on trunk doors need a small quantity of silicone lubricant sprayed internally two times per year to keep functioning correctly.

Hinge on entrance door be may be a friction type, which won't swing freely.

## **TV Antenna**

The stationary TV Antenna has a rigid base to mount the receiver head which cannot be rotated or raised up.


Base is attached to roof with screws and the antenna is attached with two bolts and nuts.

Inside of coach, on the wall is a power supply with a brown cover where you hook-up to TV and Satellite. There is an on/off button on the power supply to engage the booster, located inside of the antenna head.

This antenna also serves as a radio receiver for the sound system in the coach.

Location of this power supply is:

1. On the wall, above the space for TV, free standing or wall mounted.
2. Behind the TV.
3. Possibly on the ceiling close to TV location.



**NOTE: The Venture, Sonic models that have slide-outs, use one of the following slide-outs that are listed.**

### **SLIDE-OUTS**

With different models of trailers, VENTURE RV uses numerous slide out systems as listed below, followed by descriptions. Several different vendors supply components, loose and/or attached to frames.

1. Below floor system - All metal components are external, located under floor and in frame, inside of enclosed underbelly cover.
2. Above floor system - All components are inside and above floor, to be found under dinette or sofa slide out.

Before operating the power slide-out system in your coach, read and become familiar with these instructions, along with components and operation methods. Most of these components are enclosed and can't be seen.

### **POWER FOR OPERATION**

All power slide systems operate on 12 volt DC power provided by a fully charged auxiliary battery, which is an aftermarket item, and a converter. Thru a 12 volt distribution load center, breakers are provided for each slide. For best performance, have 120 volt AC power attached to your coach, feeding the distribution load center. Tow vehicle 12V power may also be used as required.

A automatic reset breaker is located in the distribution box feeding the operation switch to the motor.

Supplement your battery by either one of two choices:


1. Hook up a 120-volt AC power cord to recreational vehicle for converter operation.
2. Use 12 - volt power through the tow vehicle to the recreational vehicle battery or batteries.

Either of these methods will help ensure maximum electrical power for the slide-out motor, as well as maintain your battery.

## TRAILER SET-UP REQUIREMENTS - GENERAL

### Note:

1. Before operating the slide-out room, level the trailer front-to-rear and side to side.
2. Extend all stabilizer jacks to make solid contact with the ground and/or on solid blocks. Placing stabilizer jacks onto a hard surface allows the coach to remain square and assure a good weather tight seal between the room and trailer sidewall.

 **WARNING**

- ◆ Always make sure that the trailer is level before operating the slide-out room.
- ◆ Always make sure there are no obstructions blocking the path of the room when it is moving.
- ◆ Always make sure that the room path is clear of people and objects before operating.
- ◆ Always keep away from the slide rails under the coach when the room is in motion.

FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY



### BELOW FLOOR SLIDE SYSTEM

Under floor slide-out mechanism steel bars are welded to the frame members. A “cog” track is welded to bottom side of cross member, matching with a gear attached to drive shaft, “LCS (Lippert Component System.) As motor turns, a actuator moves the gear on the track ( ram ). A cross shaft, front to rear ram connects the second ram, moving the opposite end of slide. Mechanism operates the same, flush or standard floor.

### ABOVE FLOOR SLIDE-OUT

All components are located inside of coach, under dinette or sofa. Base is attached to the floor and sidewall. Top portion has a “cog” track attached to a “ram” which matches to gear on motor. As motor runs, it moves the slide in or out, as you choose. On a large slide with 2 units, a cross shaft will connect both units, operated by one motor. Access to these components is inside of coach, under slide floor.

**OPEN SLIDEOUT** Hold operation switch until room seals tightly on the exterior of the unit. DO NOT distort or bend the exterior flanges or interior fascia by holding the switch in the “ON” position.

 <b>CAUTION</b>
When opening slide room, DO NOT over-extend. Fascia board can be distorted, loosened or bent from correct position
 <b>WARNING</b>
Stand clear of the room's interior path and verify that the room's exterior path is clear before extending or retracting the room.

**CLOSE SLIDEOUT** To retract, reverse the procedure and hold button until the room is fully inside with gaskets sealing to the outer wall. It takes about 20 seconds to move the slide in or out.


**VENTURE RV** does NOT require or suggest blocking, supports, jacks, etc., to be used under slide outs during extended normal use.

### Electrical Components

A 12 volt DC motor is located under the frame. It may be inside of main rail on frame, or on some models it will be on the outer side on main rail along with front to rear shaft. On the above floor slide, it will be under the floor of the sofa or dinette. The in wall slide room system motors are installed in the wall.

*Operational switch:* This switch, is a three position, (off center, in or out) spring loaded switch. Select which direction you wish to move the room. Press on desired position and hold until room is seated, and gasket is slightly compressed. Do not force the room to move beyond sealing as damage could occur.



	<h1>CAUTION</h1>
<p>Because operating the slide-out draws up to 15 amp current from the battery, some source of supplemental charging should be operating while extending or retracting the slide out</p>	

## **MANUAL OVERRIDE**

### **BELOW FLOOR SLIDEOUT**

Should a power failure occur (no 120 volt AC power or the battery loses its charge), follow the directions listed.

There is a 1/2" shaft coming through the main rail of frame. On the end of the shaft is a 3/4" nut attached. Use a 3/4" socket with extension and ratchet to move the slide. On some units the stabilizer jack crank handle will also work on this shaft with the attached 3/4" nut.

### **ABOVE FLOOR SLIDEOUT**

#### *Manual Override (Single or Double Rams)*

Should 12 volt power fail and there is no 120 volt AC power available, follow the directions listed.

Access to the ram is under the floor of slide, sofa or dinette, and is from the front. Lippert Component System has a smaller motor, less draw and requires a 5/8" socket, ratchet and probably an extension shaft.

### **BLINDS**

Any blinds with loose cords, such as mini-blinds **CANNOT** be installed in bunks designed and built for young children.

Night shades installed, have cords anchored to lower part of window and need to be secured for operation.

VENTURE RV recommends these shades be in the UP position for travel to avoid lower metal holder being in contact with garnish on window.





## WARNING

These individual tassel cords reduce the strangulation hazard in the pull cord by removing the loop.

Do not tie cords together. Check periodically to make sure the cords have not twisted into a loop.



## CAUTION

While traveling, all mini blinds need to be in :up " position to avoid swinging and scratching paneling. Even with brackets at lower part on window, pull blinds up before traveling.

Loose furniture, such as dinette and free standing chairs, need to be secured to prevent movement, contacting walls and causing wall and chair damage during travel.

### **SAFE TEK WITH USB CHARGER**

The USB charger is a recent addition to coaches that is installed in many KZ products, some optional, others standard, operates on 12 volt power DC to charge cellphones and other items. Hook-up is RED wire, positive and BLACK wire is negative.

## MURPHY BED



# WARNING

**SUPERVISION**—For your safety and the safety of others, please **DO NOT** allow any individual under the murphy bed when lowering or on the bed when it's being raised or stowed. Children should be supervised at all times and adults should likewise instruct children about the hazards of being under the bed when lowering or on the bed when it's being raised.

**PINCH POINTS**—Beware of pinch points between the base of the murphy bed and the sofa when lowering and between the base of the bed and the storage compartment when raising and/or stowing the bed. Also beware of the pinch point between the footboard and your feet when lowering the bed and the footboard and the base of the bed when raising to stow.

**CRUSH HAZARD**—Lowering the bed may cause injury to ones self or others. Keep clear of the bed base when lowering or raising the murphy bed and ensure that no adult, child or pet are under or near the bed when lowering or raising to stow.

**USER ENTRAPMENT**-Make certain that no person is on the murphy bed when it is being raised or if the bed has not properly latched in place after it has been lowered for use. If the bed is not properly latched in place during use it may inadvertently raise up if there is enough weight on the head of the bed past the pivot point. In that circumstance a person may be trapped between the bed and the storage compartment which may result in serious personal injury or death. In addition, if someone is on the bed when it is being raised to be stowed, that person may be trapped between the bed and the storage compartment which may result in serious personal injury or death.

**MAXIMUM WEIGHT**—Know your weight. Maximum capacity of the murphy bed is two (2) average sized adults. **DO NOT** exceed 500 pounds on the murphy bed.

---

### MURPHY BED SET-UP AND STOWING

1. This is a job for two people, one on each side of the murphy bed. Before lowering the murphy bed, make certain that the sofa couch has been folded down and that no person is under the bed area.

2. While holding the murphy bed with your free hand, pull back the barrel latch pins on both sides of the murphy bed locking the bed in the upright position. The bed should be unlocked and ready to be lowered.
3. Once the pins are unlatched slide your hands underneath the footboard at the top of the murphy bed base on either side and slowly lower the bed to the horizontal position. The footboard will unfold at that time so beware of pinch points and the board hitting your feet. The bed should then rest on the foot board in a horizontal position.
4. There is a barrel latch on the side of the night stand. Locate it and make sure that the murphy is latched in the horizontal position with that barrel latch before use. If it is not latched then there is a risk that the murphy bed may swing up into the upright position if a person places too much weight at the head of the of the bed.
5. When stowing the murphy bed please again make certain that two people do so and that no one or no object is on the bed or in the storage compartment.
6. Unlatch the bed and slowly raise it to the upright position in the storage set-up position. Again, beware of pinch points and the footboard hitting your hands while being raised. While holding the base of the bed, latch the barrel latch pins on either side of the murphy bed. Make sure the bed is securely stowed before travel.

#### **FLIP DOWN CARGO TRAY**

An option called "Flip Down" cargo tray is available on numerous models of coaches. Weight limit on tray is 250 pounds, no matter what type of cargo you choose to carry. Some of these trays have the spare tire mounted on the bottom side of tray. With tire mounted on under side you MUST include weight of spare and subtract it from 250 pounds.

This cargo tray MUST be ordered before production time because main rails will be longer than normal. Mounting brackets are welded plus a bolt to swing up or down and a pin to hold it

## CHAPTER 4 SYSTEMS

### WATER AND DRAINAGE PLUMBING

Your Venture recreational vehicle has a complete water system, to carry fresh water, as well as holding tanks for used water. Each group has its own explanation along with its own operation.

### FRESH WATER SYSTEM

#### Tanks

Fresh water tanks are located and installed under the coach between frame members and protected with a cover, plus a steel carrier.

All water containers have 3 exits; (1) draw water with pump throughout the coach, (2) drain spigot for tank, (3) overflow line attached to fill vent in gravity fill.

#### Filling Fresh Water System

To place water in to your coach fresh water system, use one of the following methods.

##### A. City Water Fill See Figure 1

Water is received into the system through a direct hookup, referred to as "city water fill". Attach a hose to the hook up and supply line. Open the faucet from the supply line. Enter the unit, and open any faucet, to allow air to escape, as there will be some air pockets.

Figure 1



##### B. Gravity Water Fill See Figure 2

To place water into the fresh water tank, remove cap from fill. Insert water hose 4 to 6 inches into the 1 1/4" flex tube. Open the water supply faucet. DO NOT overfill the tank as it could burst.

It IS NOT designed to hold pressure. On the fill is a small screen, 1/2 inch at the 10:00 o'clock position. When water starts to come out—STOP FILLING NOW! It is the vent.

Figure 2





## CAUTION

DO NOT leave tank unattended while filling, as an over filled tank will built pressure, causing tank to crack, rupture, and leak or even damaging supports holding it in place.



## CAUTION

Excessive pressure from water supply systems may be encountered in some parks, especially in mountain regions. Water pressure regulators are available to protect your system against such high pressure. A regulator at 45 pound rating is recommended to prevent damage to the plumbing system or components.

### **12-Volt Demand Pump**

When water is desired and you are not hooked up to city water, your tank will be your supply. On your monitor panel is a switch to turn on the 12-volt demand pump. Energy for the pump is supplied by the auxiliary battery or converter. The pump will self-prime when started, supply water, and continue to run until approximately 40 pounds of pressure is achieved. When pressure drops to 20 pounds, pump will restart. Some cycling in pump may occur. A check valve is built within the pump to prevent water from flowing into the supply tank.


The pump has a small filter attached on the “in port “ side to prevent any foreign matter from entering the pump. You need to annually, or even more often, remove the lower cup and clean it out.

When pump is not in use, turn 12-volt power off at the switch.

Occasionally your water pump may start/stop quickly ( within a second ). This is referred to as “cycling”. The cause for this annoying noise may be a slightly open faucet, water saver washer in the end of the faucet spout, plus other restrictive issues. If pump cycles every 10 to 15 minutes, there may be a slight water leak somewhere, check valve in city water fill, plumbing fittings or pressure valve in pump.

## Faucets

The basic operation of a faucet is the same as in your home. Open the knobs for water supply. Close faucets when sufficient water volume is achieved. It is normal to experience occasional air pockets in the system.



## Bath and Shower

Your bathtub and shower are built with Vinyl, Fiberglass, or ABS plastic material, similar to those in your home. Shower curtains are provided with the coach and must be used to prevent water from spilling onto the floor, possibly causing damage.

The shower head used in the bathroom has a non-positive shutoff valve and will drip slightly in shut-off position. A vacuum breaker is also built into the faucet to permit water in hose to drain out as a code requirement.




Before beginning your shower be sure the water heater is lit. Adjust the faucet for desired temperature before entering the tub or shower. When shower is completed, be sure to turn water off at the faucet.

Used water will drain through the plumbing pipes into the gray water holding tank. Remember capacities of your water heater and gray water holding tank. Long showers in a recreational vehicle are NOT suggested due to the amount of water that is available. To conserve water, wet down, and turn water off while you soap up, then rinse.

## Outside Shower (Optional)

A convenient faucet assembly with hot and cold water is available for exterior use washing or rinsing on the outside of camper, such as washing hands and utensils.



To operate the outside shower:

1. Open the door with key and allow lid to hinge down.
2. Remove the shower head and open valve.
3. Open the faucet valves and adjust to the desired temperature.

4. To end operation close valve (s) on the faucet and allow water to drain from the shower head.
5. Close the valve on the shower head.

Any water remaining in the hose will drip or run out of the vacuum breaker. This is NOT a leak but performs as intended. Water in the ABS plastic box will drain out along outer edge.

The shower head can be removed to drain the hose faster. Reassemble and place onto bracket. Keep the door closed when not in use for sanitary reasons.

### **Fresh Water Line**


Two lines, generally red for hot and blue for cold, transport water through out the coach. Valves to direct flow are near city water fill or pump area. Connector elbows and tees are plastic or copper, and are held together with compression rings for no leakage.

### **Low-Point Drains**

Low-Point drains are placed on recreational vehicles to drain water lines, tanks, and water heater to prepare coach for winterization and sanitizing systems.

Fresh water supply tanks will have their own separate drains under the floor and/or frame, with a valve to be opened to drain, over flow drain line may be close by.

Plumbing lines also have Low-Point drains located in various areas. You may find them (2) for hot and cold water lines coming out of storage areas, outer metal skirt, through under belly covers, control centers, etc. Water should always drain out to the ground, not into underbelly cover.



## Sanitizing and Filling the Potable Water System

For your safety, you should sanitize your potable water system when your recreational vehicle is new or when it has been sitting unused for a period of time such as over winter, and it may have become contaminated.


Prepare a chlorine solution using 1/4 cup of bleach (5% sodium hypochlorite solution) to one gallon of water. Prepare one gallon of this solution for each 15 gallon capacity of the tank. As designed and constructed, this method will sanitize the plumbing system.

### For Water Lines only

1. Close all the drains, tanks, lo-point drains, and have by-pass closed to water heater.
2. With the coach completely drained, with V2 valve closed, open V1 valve and insert siphon hose into container with sanitation solution. Valves and hose are located by water pump in side compartment or in a cabinet. Start the pump to draw liquid into the system until liquid comes through the faucets. Close faucets and pump will shut off. Lines are now full.

3. Should you desire to sanitize the tank also, pour sanitation solution into the gravity water fill, which will drain into the fresh water tank.

A = Pump  
B = Filter  
C = Siphon Hose  
D = Tank  
V-1 = Valve  
V-2 = Valve



4. Add additional water to the tank through the gravity water fill. Open faucets, close V-1 valve, V-2 valve needs to be open. Start the pump to draw the liquid from the tank through the water system. When liquid flows freely from the faucets, close faucets. Pump will shut of
5. Allow this water solution to stand in the system for three hours.
6. Drain solution and flush with fresh water.
7. To remove any excess chlorine taste or odor, prepare a solution of one quart vinegar to five gallons of water and allow this solution to agitate in the tank for several days by vehicle motion.
8. Drain the tank again and flush with fresh water.



9. Your demand water system is now ready for use.
10. Be sure to TURN OFF the pump when traveling or when the recreational vehicle is not in use.

Your water system is now ready to be used. When sanitizing is completed, remember V-1 valve needs to be closed, and V-2 valve needs to be open for normal use.

The slide outs containing kitchens, will have flexible hoses installed on both fresh water lines and drain lines. Make sure there are no obstructions to allow free flow, and prevent any leakage.

### **Drainage (Fresh Water)**

All permanent fresh water tanks can be drained. The type of drain used is a turn valve with open/close position. This drain is located under the floor.

To drain the supply lines and the entire system, you need to follow the steps listed below. Locate the valve placed at the floor level or close to the floor, found under the dinette, storage cabinet, or sofa. These valves will be at the lowest point of the water lines.

#### **To Drain System:**

1. Open all faucets including optional exterior shower.
2. Open the fresh water tank drain.
3. Open the water heater drain.
4. Open all (two to four) low-point drains.
5. Open the toilet valve, hold or block if need be.
6. To empty the pump, start and allow to run up to 20 seconds.

### **Sanitation System**

#### **Toilets**

The toilet used in this model, is a Thetford, Aqua Magic Residence, with foot flush.

Prior to using your toilet, be sure to add a proper amount of deodorant chemical into the toilet with water. Flush contents into tank plus two or three gallons of water.



After each flush, about two inches of water will be in bowl, which is fine for travel.

**OPERATION:** Note the photos showing movement of pedal downward. To flush, press pedal all the way down. To add water, press pedal halfway down.




When hooked up to a sewer drain at a camp ground, ALWAYS keep the termination valve CLOSED until the tank is at least 3/4 full. This will provide sufficient water to assist in complete draining of tank.



Manufacturer of toilet, Thetford Corp., offers a complete line deodorants, chemicals, and other convenience products for your use. Your dealer can assist you with these needs and may already have them in stock.

### ***Using Toilet and Tank System***

When camping you should always have 4 to 6 inches of water in the toilet bowl. The toilet system performs better when you run water 10 to 20 seconds after flushing to ensure wastes will proceed to the bottom of the tank. Unlike your toilet at home which uses four to seven gallons per flush, the average recreational vehicle system uses two to three quarts. If there is not sufficient water used during flushing, waste materials may not evacuate properly from drain line to tank. Tank and pipes could eventually become clogged.



## CAUTION

NEVER leave the gate valve of your coach's sewage tank open when hooked up to a park's sewer system. Open only when you wish to drain system.

### ***Vents***

A very important part of your sanitation system is the vent system in your coach. These vents release air from holding tanks allowing water to enter. Vent pipes are attached to the holding tank, go through the walls. On some models a portion of vent pipe may be part of the drainage system referred to as a "wet vent". As air flows upward, water will be draining downward.



## CAUTION

Keep drain valve closed. Sewer gases may be present when RV is connected to campground sewage hookup. If drain valve is open, sewer gases may be vented out the side of the RV. (See owners manual).

### ***Holding Tanks***

The final parts of your sanitation system are the holding tanks for waste materials and water. These are located below the floor of your coach.

*Gray Tank.* Waste water from the bath tub, shower and sinks will drain into this container. No special preparation is required, however, you may wish to add baking soda or a Thetford chemical to reduce odors from food particles in the system.

*Waste Tank.* The toilet drains into the waste or “black” holding tank. For correct preparation follow the listed steps:

1. Release two quarts of water into the toilet bowl.
2. Place the recommended quantity of chemicals for waste holding tank as per instructions on the bottle into the toilet bowl.
3. Flush liquids into the tank and allow up to two gallons of water to flow into the tank.

Each time you drain the tank, you should follow the instructions listed, before using.

All drain pipes will have a “P-trap” installed into each line. Water in these traps prevent odors from escaping into the coach. During travel, water from the P-traps may spill and permit odors into the coach. These odors come from fats and food particles decomposing in the tank. By adding water and using a RV approved deodorizing agent, contents will dissolve faster, keeping the drain lines and tanks clean and free flowing. These chemicals are available at a RV supply store.

### ***Draining the Tanks***

A final part of your sanitation system is the drainage of holding tanks. Realizing dump stations will vary, place the coach as level as possible to make drainage easier. Some tanks drain from the center

requiring unit to be level or slightly up in front. Others will drain from end permitting a slight tilting to the side which drains are on.



## CAUTION

It is important to use adequate water to flush and have several gallons of water with chemicals in the tank. This helps the flow of wastes and reduces solid waste build-up.

Remove the cap and attach the adapter onto the valve housing. Turn the adapter 10° to lock onto the pegs. Attach a flexible sewer hose to the adapter and secure with a clamp. Place the other end into the approved sewer system.

You may now open the 3 inch drain valve to drain the sewage tank first. Open the valve on the gray water tank last to utilize water to wash and rinse the hose and drain lines.

Most states and parks have strict laws and regulations to prohibit dumping of wastes of any kind into anything other than proper disposal facilities or sewer systems. Almost all privately owned parks have either a central pump facility or offer a campsite hookup for sewage. You can find lists of many dump facilities throughout the United States in *Woodall's*, *Rand McNally Camp Guide*, *Good Sam Camp Guide*, *KOA Campgrounds Camp Guide*, or various other publications. Some fuel stations also have dump stations.

### **BLACK TANK FLUSH SYSTEM—OPTIONAL**

The flush system is designed and built to rinse the waste holding tank, AFTER waste tank has been drained completely of water and solids.

#### **CAUTION**

1. Attach a fresh water source to the connection marked "Sewer Tank Flusher". Be sure termination valves are open on tanks.
2. Open valve to release water into tank for rinsing and cleaning of your waste water holding tank.
3. Rinse for several minutes to remove any foreign matter from tank, and probes **FOR PERSONAL SAFETY**.

Remember the moisture content may give you a false reading on your monitor panel indicating it is full. Allow time to dry out tank or recharge for next usage.



## CAUTION

Sewer Tank Flusher- Sewer valves must be OPEN when using this inlet. Can result in unsanitary conditions causing illness and personal injury

### ***Maintenance for Holding Tanks***

The following maintenance is recommended by our holding tank suppliers to keep your tanks clean and keep the probes free of debris and build-up.

*Gray (Waste-Water) Tank.* Fill tank with 8-10 gallons of warm water. Add a degreaser such as a citrus cleaner or Dawn dish soap. Leave solution in tank while you are traveling. Rinse and drain tank.

*Black (Sewer) Tank.* Fill tank with 8-10 gallons of water. Add one bottle of drain cleaner, such as Drano or Liquid Plumber. Leave the solution in tank while traveling. Rinse and drain tank.



## WARNING

DO NOT use Ethylene Glycol (automotive antifreeze) or Methanol (windshield washer antifreeze) in your fresh water system because they are harmful and may be fatal if swallowed!

### **Winterizing Your Recreational Vehicle**

Preparing your trailer for cold weather is very important for most states and Canada. Failure to prepare your coach for cold weather will cause the water systems to freeze resulting in breakage. Damages related to freezing are not covered under the terms of your limited warranty.

Two methods of winterizing your coach after draining and flushing your drainage system are listed below.

#### *Method 1:*

1. Open all faucets, low point drains and toilet valve to drain all water. Leave these open during this procedure.
2. Start pump and operate until all water has been removed, takes about 10 to 15 seconds.

3. After water has been drained, use an air hose from compressor and an adapter attached to city water fill. In about 3 to 5 minutes all water will be blown out of system.
4. Pour one (1) cup (12 oz) of non-toxic RV anti-freeze into each P-Trap. Each sink has a P-Trap, as does the bathtub.

*Method 2:*

The water heater bypass kit is designed and built to avoid having antifreeze in the water heater.

1. Be sure to turn off the pump.
2. Drain the water heater and the entire water system.
3. Close the valve on the bottom and top of the by pass kit to prevent liquid from entering the water heater.
4. Place siphon hose into container with anti-freeze.
5. Open the valve on the siphon hose, which is valve V-1 from diagram on page 48. Valve V-2 needs to be closed.
6. Turn on the pump to supply the fresh water system with anti-freeze. It will take 2 gallons or more, depending on the size of the coach.
7. Close faucets when lines are full. Allow 1 pint of antifreeze to enter in each of the three traps.
8. Shut off the pump. You may wish to re-open the faucets to remove pressure from the lines.

**BY PASS KIT**

Valve in horizontal position allows water to flow into and through water heater. Valves of by-pass are choice directional flow, not a shut off.

When both valves are in vertical position, it will prevent water from flowing through the water heater. Now you can send anti-freeze liquid through coach plumbing system without filling water heater.

*Using the Water System During Freezing Weather.* Your towable RV was not intended to be used during freezing weather unless special precautions are taken. Water freezes at 32° Fahrenheit in campgrounds or at home.

There is no product that can be added to the water to ensure freeze protection when the system is in use, other than RV anti-freeze. DO NOT drink water which contains anti-freeze.

## **PROPANE FUEL SYSTEM**

---

The fuel system in your recreational vehicle has numerous components such as, piping, copper tubing, brass connectors, hoses, regulators and appliances. Each of these components will be explained in its appropriate area.

Propane is the only fuel permitted to be used in a recreational vehicle and its appliances. This product is refined from crude oil through natural gasses. An agent has been added for detection should a leak occur or a valve accidentally be left open. It is important for a recreational vehicle owner to recognize and identify the smell of propane vapor.

Other fuels are available but CANNOT be used in a RV..

1. No orifices for appliances are available for either butane or natural gas fuels
2. Butane also CANNOT be used below freezing temperature because boiling point is 30 degrees F.

Propane fuel is stored in liquid form under high pressure in special containers. Boiling point is ( minus) - 44°F, the temperature when vapor ceases to flow. Fuel will change to vapor when released from the container. Appliances are not designed to operate with liquid. Liquid will damage o-rings in valves and also leave sticky, oily residue causing poor or no operation in the regulator.

For every 10 degree increase in temperature, the pressure in container rise's 1.5%. Example—fill at 0 degrees in north, go South to 80 degrees warmer, you now have container filled at 92%, a potential problem with vapor spewing out of 10% valve.

### **Propane Container**

The propane cylinder is a D.O.T. approved container to hold liquid under high pressure, normally a 20 or 30 pound capacity.


The open/closing valve, referred to as an OPD cylinder valve, is to be closed at all times unless hooked up to a propane system or when filling the container.

Valve assembly actually has 3 valves in one body.

1. Main pass thru portion to fill container and draw propane out is controlled by upper 3-sided knob on top.

2. A small screw on the side of main body referred to as the 10 % valve which allows air to be released and indicates when container is at 80 % capacity.
3. Incoming positive seal valve MUST be pushed inward with fill nozzle to fill or by POL fitting to draw vapor out for appliance use.

**OPD Cylinder Valve**



On the bottom side is the float which closes when 80 % of capacity has been reached. This permits expansion space in the tank when temperature rises. See section on main hoses.  
At any point a container is disconnected, BE SURE to install the dust cap or plug over entry (if so equipped).

Whenever the container is detached from the propane system , DO NOT allow the cylinder to move or roll around during transportation to and from the gas supplier.

### **Servicing and Filling Propane Containers**

Filling a propane container must be done carefully and correctly. Only a qualified person, properly trained on inspection, filling and safety procedures, should fill container.

To remove the propane containers for refilling.

1. Remove the bottle covers ( if used ).
2. Close the main valve on the container.
3. Remove the two hoses from the ACME connection.
4. Install the rubber cap over the valve - ACME connection. (if so equipped)
5. Remove/loosen the wing nut holding the clamp hook.
6. Remove the clamp hook.
7. Fill the bottle and reverse the procedure to install. Test all connections for leakage.

A new container MUST be “purged” before placing into service and MUST NEVER BE OVERFILLED. Purging is an operation performed by your dealer or propane agency to remove any atmospheric air. As an owner you need not be concerned regarding this procedure unless you permit the valve to be in OPEN position when empty.

Two overfill devices are built into the valve to prevent overfilling of




the container. First, is the small brass “knob” or “screw” inside of the valve. This “10% valve” must be open when filling, allowing air to escape. When the container reaches 80% of the correct capacity, liquid appears. Shut the supply filling valve off. Close the 10% valve plus the top handle of the main valve.

When refilling propane containers, they are generally removed from propane compartment or tie downs. BE SURE to reinstall correctly, as shown in installation instructions, and test for leaks.

When propane containers are filled to 80% level there is available space for safe expansion of the vaporized liquid. Should your container become slightly overfilled, pressure may rise due to hot sun.

It could cause the overflow valve to “blow-off” and emit a small quantity of propane vapor. This can be detected by a strong odor around tanks. Keep open flames away from this area. It is best to remove the bottle, take it to a safe area, and “bleed-off” the excess pressure by opening the valve slightly and closing it when discharge has been sufficient, one to two minutes.

When disconnecting propane containers, you must turn the acme fitting in a clockwise direction because left-hand threads are utilized. When reconnecting, turn connections counterclockwise. Connections must be tight, however DO NOT over-tighten.

	<h1>WARNING</h1>
<p>Your vehicle has exterior combustion air inlets. Appliance pilot lights should be turned off during gasoline or propane refueling. (Required by law in some states.)</p>	

### **Installing Propane Containers**





Venture recreational vehicles are equipped with 20 or 30 pound propane containers, depending on floor plan models.

Mounting and attaching instructions are listed below:

1. Thread the long rod into the base plate.
2. Set both bottles into place as shown.
3. Drop the double hook bracket over the rod and hook onto the bottle.
4. Attach the wing-nut to hold the bracket and tighten to hold the bottle to the plate.
5. Attach the regulator with the vent down to the bracket.

6. Attach the main hose from the regulator to the manifold fitting in the frame.
7. Attach two short pigtail hoses to the regulator and bottles at the ACME fitting.
8. Test all propane connections for leakage.

A warning label has been located near the propane container. This label read as follows:

 <b>DANGER</b>
All pilot lights, appliances and their igniters (see operating instructions) shall be turn OFF before refueling of motor fuel tanks and/or propane containers. FAILURE TO COMPLY COULD RESULT IN DEATH OR SERIOUS INJURY.
 <b>WARNING</b>
A warning label has been located near the propane container. This label reads as follows: DO NOT FILL CONTAINER(S) TO MORE THAN 80 PERCENT OF CAPACITY. <ol style="list-style-type: none"><li>1. Overfilling the propane container can result in uncontrolled gas flow, which can cause fire or explosion.</li><li>2. A properly filled container will contain approximately 80 percent of its volume as propane.</li></ol>
 <b>WARNING</b>
Never smoke during the filling of propane tanks. Keep the recreational vehicle away from immediate filling area when possible or extinguish all gas pilots.
 <b>CAUTION</b>
DO NOT use tools to open or close the tank valve. HAND TIGHTEN ONLY to avoid damage to the valve or handle.



## WARNING

Propane cylinders shall not be placed or stored inside the vehicle. Propane cylinders are equipped with safety devices that relieve excessive pressure by discharging gas to the atmosphere.  
FAILURE TO COMPLY COULD RESULT IN DEATH OR SERIOUS INJURY.



## CAUTION

THIS GAS PIPING SYSTEM IS DESIGNED FOR USE WITH PROPANE ONLY. DO NOT CONNECT NATURAL GAS TO THIS SYSTEM.  
Securely cap inlet when not connected for use. After turning on gas, except after normal cylinder replacement, test gas piping and connections to appliances for leakage with soapy water or bubble solution. Do not use products that contain ammonia or chlorine.

### Regulator

Regulators that are not in compartments have been equipped with a protective cover. Make sure that the regulator vent faces downward and that the cover is kept in place to minimize vent blockage that could result in regulator failure to operate

The regulator has the only moving components in the propane system. It's sole function is to reduce the high and varied pressure from the propane containers to safe and consistent low operating pressure. The small inlet is the first stage, which reduces the container pressure to 10-13 pounds.

The second stage then reduces the 10-13 pound pressure to an operating pressure of 11 inches w.c. (water column) or 6.35 ounces of outlet pressure to your appliances. The second stage is adjustable and may need to be adjusted for precise operation. We suggest this to be normal maintenance and performed once per year. Do not make this adjustment without a manometer. This instrument is required to read actual pressure.

If pressure is too high, it affects performance and safety. Should pressure be too low, appliances will not operate correctly. An




authorized technician with proper equipment should perform such tests and adjustments, as may be required.

The propane regulator used on the Venture units, is the automatic two stage regulator. With both cylinders full of propane, turn the lever on the regulator towards the cylinder you wish to use first. This will now be the "supply" cylinder and the other "reserve". Slowly open both cylinder valves.

The "Supply" side of the regulator will continue to supply propane as long as sufficient propane remains in the "Supply" cylinder. When pressure in the cylinder drops to about 10 psig, the "reserve" side of the regulator will open and continue to regulate at 11" WC. At the time the "supply" cylinder becomes exhausted, a red warning flag appears in the indicator window. This red or orange flag indicates that a cylinder exchange can be made.

Before removing the empty cylinder, close the valve to prevent air from entering to cylinder.

After filling the cylinder, connect the pigtail hose and slowly open the bottle valve. Do not forget to check for leakage each time you refill cylinder or disconnect any part on the propane system.



1. Knob to open and close main valve.
2. Complete valve assembly.
3. "10% valve", (small brass knob or slot screw).
4. Container mounting stand.

## CAUTION

If you have double bottles and a standard regulator on your RV, use only one bottle at a time. Otherwise the gas supply will be drawn equally from both bottles until supply has been totally exhausted. Using one bottle until it is empty, then using the second bottle will allow you to fill the empty bottle at your convenience without being totally out of propane.

### High Pressure Hoses with Acme Connectors

Propane leaves the container through a hose with an ACME connector attached to the bottle, also having a “flow-limiting device” designed to sense **excessive** flow. Two functions of this device: 1. should the container valve be opened too quickly this device may close, stopping the flow of propane. 2. Should there be a rupture in propane line, it will reduce the flow to a maximum of 10 (SCFH) Standard Cubic feet per Hour.

This device will equalize normal flow in about 5 seconds, generally not noticeable.



### Main Supply Hose – Low Pressure

The main supply hose will be attached from the regulator to the brass manifold fitting in the frame of the coach. The swivel brass nut on the main hose will be your final attachment.



3/8" MPT x 1/2" Female  
Flare Swivel

There are several things to remember each time the container is removed:

1. Be sure ALL fittings are tight. Always use two OPEN END wrenches for brass connections.
2. Be sure ALL connections are tested for leakage.
3. Open the main valve slowly to avoid a fast rush of propane to flow-limiting device causing propane “freeze”.
4. Listen carefully – a “hissing” sound longer than one second may indicate a propane leak. Close valve and search for leak.

Should you experience a propane “freeze-up”, close the main valve and wait 15 minutes before trying again. Keep the container valve(s) closed when traveling. Some states prohibit traveling with the propane container valves open, especially in underground tunnels on expressways.

### **Operation**

After the camper is completely set up and you are prepared for camping enjoyment, follow these steps for propane operation.

1. Be sure ALL burner valves, controls, and pilot light valves are closed.
2. Open main valve on propane container SLOWLY to avoid a fast rush through excess flow valve causing “propane freeze”.
3. Listen carefully as propane begins to flow. If a “hissing” sound is heard for more than one or two seconds, close valve and search for a potential leak.
4. Light appliances as needed and directed in Chapter Five - Appliances.


### **Checking for Leaks**

The entire propane distribution system and appliances have gone through complete factory and dealer tests for any leakage. When traveling with your RV, normal vibrations and road movement may cause connections to loosen and develop leaks.

For normal maintenance we advise all owners to test for leakage at least once per year or more often. You may request your dealer to perform a maintenance check each spring.

Should you encounter an odor, possibly propane, turn off any and all open flames and begin a systematic search for leaks on the complete propane system. NEVER USE A MATCH. Use a soapy water solution which contains NO AMMONIA, or CHLORINE content to check for leaks. If a leak is identified, bubbles will appear. ALWAYS use two open end wrenches when tightening brass connections to prevent twisting of copper.

For your own protection, the following warning label has been placed near the cooking area to remind you of the need of oxygen for combustion and breathing. Due to smaller area in your recreational vehicle, there is less oxygen than in your home. Proper ventilation is required when cooking.

DANGER

IT IS NOT SAFE TO USE COOKING APPLIANCES FOR COMFORT HEATING. Cooking appliances need fresh air for safe operation.

Before operation:

1. Open overhead vent or turn on exhaust fan.
2. Open window (s).

**FAILURE TO COMPLY COULD RESULT IN DEATH OR SERIOUS INJURY.**

Unlike homes, the amount of oxygen supply is limited due to the size of the recreational vehicle, and proper ventilation when using the cooking appliances avoids danger of asphyxiation. It is especially important that cooking appliances not be used for comfort heating, as the danger of asphyxiation is greater when the appliance is used for long periods of time.

It is especially important that cooking appliances **not be used for comfort heating**, as the danger of asphyxiation and unsafe levels of carbon monoxide are greater when the appliance is used for long periods of time.

### **Propane Consumption**

All your propane appliances are operated intermittently. Your furnace is naturally the appliance using the most fuel, especially if freezing conditions are present outside. On a very cold and windy day it is conceivable that your coach could consume most of a 30 pound propane bottle.

Propane consumption depends mostly upon individual use of appliances and the length of time operated. Each gallon of propane produces about 91,500 BTUs of heat energy. Following is a list of typical appliance consumption when turned on fully for one hour of operation:

APPLIANCE	LP GAS CONSUMPTION
Water Heater	12,000 BTU
Furnace	20,000- BTU
Stove/Oven	6,500-9,100 BTU
Refer	1,200-2,200 BTU
Note: The above chart represents many different models.	



## WARNING

Portable fuel-burning equipment, including wood and charcoal grills and stoves, shall not be used inside the recreational vehicle. The use of this equipment inside the recreational vehicle may cause fire or asphyxiation.



## DANGER

### If You Smell Propane:

1. Extinguish any open flames, pilot lights, and all smoking materials.
2. Do not touch electrical switches.
3. Shut off the propane supply at the tank valve(s) or propane supply connection.
4. Open doors and other ventilating openings.
5. Leave area until the odor clears.
6. Have the propane system checked and leakage source corrected before using again.


**FAILURE TO COMPLY COULD RESULT IN EXPLOSION RESULTING IN DEATH OR SERIOUS INJURY.**

**ALL GAS LINES HAVE BEEN CHECKED WITH AIR PRESSURE. DEALERS ARE REQUIRED TO RECHECK BEFORE DELIVERY TO RETAIL CUSTOMERS.**



## **ELECTRICAL SYSTEM**

### **General Information**



30-A, 125-V, 2-pole, 3-wire,  
grounding type

The electrical system in your recreational vehicle is designed for using both 120 volt AC (alternating current) and 12 volt DC (direct current) capabilities. All installations and designs are built to comply with safety requirements of ANSI standard 1192, National Electric Code and Canadian Standards Association.

This model manufactured by VENTURE RV has 30 amp system.

**Highly recommend that your RV electrical connection, is not plugged into a household outlet.**

### **Changes and Modifications**

Any changes, alternations, additions, and/or modifications need to be performed by qualified electrical technicians, using only approved components which meet safety and code requirements. This includes owners, dealers, etc. who desire to make changes. The manufacturer is not responsible for any changes, or alterations, made to the 120 AC system of the coach.

### **120-Volt A/C System**

Power Cord 30 AMP




The 30 amp rated power cord is not pre-wired into the breaker box. Open the hatch door as shown, on the exterior of the coach. Pull cord out from interior storage and attach it to incoming 120-volt power source and your RV.


This cord places 120 AC volt power into your breaker distribution center, as built into your coach, also rated at 30 amps.

Energy will enter through the main breaker and is distributed through circuit breakers to the wall receptacles and appliances. This power cord will be approximately 26 to 28 feet in length. Each cord has the correct gauge of wire to carry the correct voltage to the coach.

In some hook-ups the power cord may not be long enough and extension cords are required. Always use a cord with the gauge of wire equal to or greater than the power cord. Should you use a cord with a smaller wire gauge, overheating, loss of amperage, and possible melting could occur.

DO NOT leave any unused portion of an extension cord in a “coil” as it may overheat, short-circuit wires and potentially destroy your extension cord.



 **WARNING**

Never use a “cheater” plug or extension cord which breaks the continuity of the ground circuit to the grounding pin.

***Circuit Breakers and Box—120 VAC***

On a 30 amp system, a maximum of six distribution circuits are permitted. All breakers are sized according to power needs on each line.


The following generic drawing shows the circuit breaker alignment with number one being the main breaker on all floor plans. Depending on the size, floor plan and options of your coach, circuit three through six will vary and possibly not all circuits will be used. Number two is generally the 20 amp air conditioner circuit.

An owner must realize and understand that a coach has a total of 30 amp service available to be used. Conserving and choosing which appliance has priority in consumption needs to be part of the planning.

Don't forget loose items such as toasters, electric skillets, and coffee pots also consume power. Include these also in your planning.

 **WARNING**

Do not replace breakers or fuses with any that are rated at a higher amperage. Over fusing may cause a fire by overheating the wire.



**! WARNING**  
 NEVER, under any circumstances, remove a grounding pin in any cord or plug. It may mean the difference between LIFE OR DEATH.

***GFCI Protection***

Each coach has a GFCI, Ground Fault Circuit Interrupter, protection receptacle installed into the circuitry. This GFCI device is designed to protect people from hazards of line to ground electric shock. The purpose is to reduce possible injury caused by electrical shock, resulting from faulty insulation and/or installation, improper polarity and related to moisture and/or earth ground.

The third “round” pin on the receptacle is very important for this safety device to function correctly. NEVER cut off this pin. When using an appliance in the receptacle without this provision, use an adapter with a pigtail adapter to be attached to the receptacle box to complete the circuit.

This GFCI receptacle will not protect against short-circuits or overloads. The circuit breaker or fuse in the electrical panel which supplies power to the circuit provides this protection.

Polarity is extremely important. You should be certain that the polarity of the external power is not reversed, in order to avoid harm to appliances and personal electrical shock. Polarity testers may be purchased in most electrical and hardware stores with the GFCI tester built in.

During use of the recreational vehicle it is suggested to test this receptacle once per month. To test, press the "TEST" button in. The "RESET" button should pop out. Power should now be turned off at this receptacle and any receptacles down line. To restore power push, then release the "RESET" button.

### **12-Volt DC System**

Most interior lights and appliances receive 12-volt DC power through converter output and/or the auxiliary battery. Exterior lights and brakes also use 12-volt DC power from the tow vehicle battery and/or auxiliary battery through the seven way connector and wire attached to the tow vehicle. Following are explanations of various items.

#### ***Converter***

The heart of your 12 volt DC system is enclosed inside of the load center, including 12V fuse panel, 120VAC breaker panel, and converter.

Fuse panel may have numerous fuse positions, depending on output size of your converter.

All converters have solid state electronic components internally to produce "clean" 12V DC power.

This load center will have a brown plastic front with a small door to access fuses and breakers.

The function of a converter takes 120-volt AC power and transforms this energy into 12-volt DC power as used in your coach. 12-volt DC supplies power for some appliances and most interior lights. The floor plan and size of coach indicate the output size.

When the converter receives 120 AC power, it transfers power into 12-volt DC without any manual switches. The converter also charges the auxiliary battery (s) when installed on the coach and is attached to 120-volt AC power. The third function of a converter is to send 12-volt power to the fuse panel and throughout the coach.

Each converter has a “built-in” fan which operates through a load sensor control or temperature sensor. As more current is drawn, fan will speed up, run faster, or slow down, based on amp draw and/or temperature. Should the fan not run at all, the converter may overheat and will cut-out and/or stop.

### ***Auxiliary Battery —NOT OEM available***

All travel trailers and fifth wheels are pre-built to accept a battery. Batteries are not standard equipment on units.

Recommended batteries are of deep-cycle type as you need longer, slow consuming power rather than cold-cranking power. A battery is always required for a break-away switch to function.

A battery requires routine maintenance for long life. First, terminals need to be kept clean to avoid corrosion. Second, a battery used daily will consume water as long as the converter is in operation. Be sure to check the battery no less than every 30 days and keep the battery filled with distilled (rain) water. Most good deep cycle batteries are NOT maintenance free.

A converter will not overcharge a battery unless a battery has a dead cell, or the converter has a malfunction. Some type of converters have full battery charge shut-off. Other types reduce the rate of charge as battery conditions reach 12.7 volts DC or 1.265 specific gravity at 80°F. By electronic standards, a battery is discharged at 10.5 volts. Dropping voltage lower than 10.5 volts will begin damaging plates in the battery.

The interior lights will operate from the converter and/or auxiliary battery. Some lights will have wall switches and other lights have switches in the lights themselves.

### ***Circuit Breakers and Fuses—12 Volt DC***

These two items have been installed in your coach to protect circuitry and components:

Fuses are placed into the fuse panel with the converter or into a separate panel near the converter with access inside of coach. Fuses are placed in your electrical system to protect wiring and components when overloads appear or short circuits occur. Radios, stereos and possibly other components may have “in-line” fuses attached to their own wire harness.


Circuit breakers are placed at several locations. An automatic reset breaker is placed within 18 inches of the auxiliary battery. Breaker will automatically reset upon “cool down”, normally 60 seconds.



Two 40 amp or four 20 amp fuses are placed in the converter to protect convertor should you hook-up a battery backwards. Fuse will blow instead of converter.

A 30 amp automatic reset breaker is installed in the load center to operate your slide-out( s).

All wiring used in your coach meets correct amp rating correlated with fuses and breakers in respective panels as required by code.

WARNING


DO NOT replace circuit breakers or fuses with a higher current rating than those supplied with your coach. Over-fusing can cause a fire hazard by overheating the electrical wiring.

The RV battery is placed in parallel circuitry with the battery on your tow vehicle. Care needs to be exercised not to drain both batteries together. There are two methods of avoiding this condition:

First, disconnect the tow vehicle when parked and/or using your coach.

Second, a battery isolator may be installed in your tow vehicle to prevent power drain from batteries in both vehicles. This device “isolator” has two useful purposes. First, it sends current from the alternator to both batteries simultaneously. Secondly, the isolator prevents draw from the recreational vehicle through the battery of the tow vehicle, preserving power to start the engine.

Contact your dealer should you desire an isolator for your protection. Two types are available, mechanical type, or solid state which is the best and most expensive.



### **Exterior Lights and Connector, 12 Volt**

Power for exterior lights, such as tail lights, turn, clearance and brake lights, is supplied by the tow vehicle.

Note the diagram (above) showing the color code and numbers from the seven way connector and how power is fed to the exterior lights. The positive red wire is attached to the battery to transfer power to the coach.

The connector between the recreational vehicle and the tow vehicle may build up corrosion due to moisture. You may need to clean these terminals occasionally to insure good electrical contact.

### **Porch Lights**

Porch lights are placed on sidewalls, left and right side. Switches for these lights, depending on models, will be in the interior, right ( door side ) side wall. Occasionally, the switch will be on the light itself.

### **Brake Wiring**

The 10 inch electric brakes operate on 12-volt power supplied from the tow vehicle, transferred through the blue-positive and white-negative in the seven way harness. There are no fuses or breakers installed in this brake wiring. More information on the brake system is found in Chapter Three - Using Your RV.

If experiencing any electrical problems, check the following items, fuses, breakers, and connections. If none of these items resolve the problem, contact your dealer for trouble shooting, and needed repairs.

**FURRION** is a solar panel connection, for portable panel, placed in sun light, on the ground or a table. Only the hook-up connection has been installed in this RV.

Charging your auxiliary battery is it's main function.

The actual solar panel is an after market item and not available from or thru manufacture of this RV.

You would use this system only when 120 VAC is not available.



## CAUTION

Any electrical installation that does not meet the criteria of the manufacturer's specification will VOID THE WARRANTY on the electrical system.



## CHAPTER 5 APPLIANCES

VENTURE RV places brand name, quality-built equipment, as guided by current codes and standards, in all recreational vehicles. Some appliances are built and equipped to operate on propane gas ONLY. DO NOT attempt to operate on natural, butane or methane gas.

Each appliance has its own specific manual, written and published by its manufacturer. These manuals supply additional information about the appliances in your recreational vehicle.

### **SAFETY—READ BEFORE OPERATING**

The first four appliances in this chapter, all use propane for their MAIN source of fuel, plus some use 12 volt DC and 120 volt AC energy also. Chapter 4 has more information on propane .

IT IS VERY IMPORTANT THAT YOU AS AN OWNER AND OPERATOR ARE FULLY AWARE WHAT PROPANE ODOR IS OR SMELLS LIKE, FOR YOUR PROTECTION.



## DANGER

### **What to do if you smell Propane.**

This section involves all appliances which use and consume propane, may or may not have a pilot light.

1. Extinguish any open flame.
2. Evacuate all persons from vehicle.
3. Shut off the propane supply at container.
4. DO NOT start any engine or generator.
5. DO NOT touch any switch, phone, or radio in vehicle.
6. Contact the nearest propane supplier, service technician, or fire department personnel.
7. DO NOT turn propane supply on until problem or leak has been solved.

**FAILURE TO COMPLY COULD RESULT IN  
SERIOUS INJURY, EXPLOSION, OR DEATH.**

BEFORE OPERATING, take note of any unusual odor in coach, near floor or elsewhere similar to propane.

Each appliance has it's own manual, be sure to read and obey all instructions as written by manufacture.

## **FURNACE**

---

The furnace in your recreational vehicle requires 12-volt DC electrical current and propane gas energy for correct operation. The furnace receives 12-volt DC power from a fully charged battery and/or the converter in the coach. This power must be present before propane gas can enter through the control to the burner tube.

The combustion chamber is completely sealed to prevent any carbon monoxide from entering into the coach. Oxygen is drawn into the chamber through the upper vent and exhaust fumes expelled through the lower vent.

	<h1>WARNING</h1>
DO NOT operate furnace while vehicle is in motion or being towed.	

The basic operation of furnace is performed by thermostat mounted on interior wall of your coach.

## **THERMOSTAT**

Has an on/off switch and temperature setting on top. From the time you turn the thermostat on, there is a delay built into the furnace to form a purge cycle, preventing any possible propane vapor buildup in the chamber of the furnace.

**NOTE;** Different model furnaces are used for different unit floor plans. Each model furnace has it's own Users Manual. The following instructions may vary slightly from the instructions in your unit. Therefore, refer to the users manual provided in your unit



## Operating Instructions

1. Before using your furnace, it is suggested to open entrance door and windows to ventilate camper for any unusual odors such as propane or other.
2. Be sure propane container has fuel and valve is turned open.
3. Release thermostat from OFF position .
4. Set thermostat to 5 to 8 degrees above room temperature.
5. Blower will start in 0 to 15 seconds, run for 30 seconds during heat chamber PURGE cycle, to remove any propane vapor from chamber.
6. Second cycle, blower continues to run, module board will; (a) send spark to the burner tube; (b) open valve to release propane to the burner tube.
7. Ignition attempt will be for 7 seconds.
8. Failing to ignite, board will make 2 more attempts to light the burner and then go to lock-out.
9. If after (3) attempts with no ignition, drop thermostat to lowest setting, wait 1 minute and repeat the same steps, 3 to 9.
10. After burner lights, set thermostat at desired at desired setting.
11. To shut burner down, move thermostat to lowest setting or OFF.
12. Blower will continue to run for about 2 minutes until heat is removed from chamber.


This furnace is equipped with a 12 volt shut-off switch. With switch turned "OFF", furnace will NOT operate, propane will not flow to burner nor will furnace operate. To locate this switch, a cabinet panel may need to be removed.

NOTE; During initial firing of this furnace, a burn-off of excess paint and oils remaining from manufacturing process may cause "smoking" for five to ten minutes. Your dealer may have already performed a "burn-off".



- A. Use only your hand to turn the handle on the manual shut off valve. Never use tools. If the handle will not turn by hand, don't try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.

- B. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.



# WARNING

Do not install screens over the vents for any reason. Screens will become restricted and cause unsafe furnace operation. Accessories are being marketed for RV products which Venture RV does not recommend. For your safety, only factory authorized parts are to be used on your furnace.

**External Vents.** Always be sure these vents are clear of any objects like screens, duct tape, etc.

**Ducting.** This furnace is called a “BLOW THRU “ system and no duct work is used. Any restrictions in front of grill, will prevent the furnace from correct operation. Never block grill off completely, possibly causing furnace to limit out and shut down.

Propane pressure, as defined in Chapter Four - Systems, is extremely important. A dial gauge or U-tube manometer is required to perform tests and adjustments. Pressure must be set at 11 inches w c. (water column) plus or minus 1/2 inch. Incorrect gas pressure can cause any appliance to operate inconsistently and cause poor combustion. Only qualified technicians with proper equipment should make any mechanical adjustments.

Voltage must be between 10.5 volts to 13.5 volts at the furnace during operation. Below 10.5 volts the furnace will shut down. Both high and low voltage places excessive wear on the motor and brushes.

Any mechanical adjustments, such as electrode adjustments, should be performed by a qualified service technician

## **DROP-IN COOK TOP**

The cooking appliance used in the Venture RV, Sonic models, is a 2 Burner Drop-In Cook top. These appliances operate with propane gas only, never natural gas or methane. This model of stove DOES NOT have a free standing pilot light.

## **OPERATING INSTRUCTIONS**

1. Know which knob controls which burner. Always be sure the correct burner is turned on.
2. Depress knob and turn fully counter-clockwise to "Lite" position.
  - a. Verify sufficient propane supply before attempting to light burner. Air in the gas line will significantly delay burner ignition. The burner may light unexpectedly as the air in the lines clears and is replaced by propane. This unexpected ignition could burn you. Air in the gas lines may occur after the vehicle gas bottle and/or tank is refilled, during and after servicing other appliances on same propane line, etc.
    - b. Do not attempt to light more than one burner at a time.**
    - c. Immediately light burner by holding a long match near the burner ports.
3. If any burner should extinguish after initial lighting or due to accidental blow-out, turn propane off by turning control knob clockwise to "OFF", wait five (5) minutes before attempting to relight the burner. Failure to follow these instructions could result in a fire or explosion.

If the burner should go out while cooking, or if there is an odor of propane, turn control knob (s) clockwise to 'OFF'. Wait five (5) minutes for propane odor to disappear. If propane odor is still present—Do not relight burners, See "What To Do If You Smell propane" on the front cover of the Cook Top manual.
4. To turn burner( s) "OFF", turn the appropriate control knob clockwise to "OFF".





## CAUTION

Hand held igniters may be used but be sure they are the type designed for lighting open flame burners.



## WARNING

Be sure all control knobs are turned "OFF" when you are not cooking. Someone could be burned or a fire could start if a burner is accidentally left on or unattended even if only momentarily.



## WARNING

If the user of this appliance fails to maintain it in the condition in which it was shipped from the factory or if the appliance is not used solely for its intended purpose or if appliance is not maintained in accordance with the instructions in this manual, then the risk of a fire and/or the production of carbon monoxide exists which can cause personal injury, property damage or loss of life.



## DANGER

ALL PILOT LIGHTS, APPLIANCES AND THEIR IGNITORS (SEE OPERATING INSTRUCTIONS) SHALL BE TURNED OFF BEFORE REFUELING OF MOTOR FUEL TANKS AND/OR POPANE CONTAINERS. FAILURE TO COMPLY COULD RESULT IN DEATH OR SERIOUS INJURY.



## WARNING

DO NOT OPERATE THIS APPLIANCE UNLESS THE PRIVACY CURTAIN IS SECURED. FAILURE TO COMPLY COULD RESULT IN FIRE OR SERIOUS INJURY.

## **WATER HEATER**

---

### **SAFETY INFORMATION**

FOR YOUR SAFETY READ SAFETY INSTRUCTIONS ON  
PAGE 74.

### **OPERATING INSTRUCTIONS—GAS**

- A. This appliance does not have a pilot light. It is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.
- B. This is an automatic propane valve, no adjustments are necessary. Do not attempt to repair the propane valve. This may result in a fire or explosion.
- C. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.
- D. Before operating water heater, check the location of the vent to make sure it will not be blocked by the opening of any door on the trailer. If it can be blocked, do not operate the water heater with the door open.

### **OPERATING INSTRUCTIONS FOR UNITS WITH DIRECT SPARK IGNITION GAS VALVE.**

- 1. STOP! Read the safety information provided.
- 2. Turn off all electric power to the appliance.
- 3. Turn "OFF" propane supply.
- 4. Wait five minutes for propane to clear the area. If you smell propane, then STOP! Follow instructions in item B of the safety information. If you do not smell propane, go to the next step.
- 5. Turn "ON" the propane supply.
- 6. Turn on water heater appliance at monitor panel for propane operation.
- 7. Turn switch marked "GAS", which is located on the bottom of the monitor panel, to "ON" position. If the burner does not light, the system will automatically attempt two more tries for ignition before lock out. NOTE: Each ignition cycle will have a fifteen second purge before spark cycle if the system is a three try system.

8. If lock-out occurs before main burner lights, turn switch to “OFF”, wait five seconds and turn switch to “ON” position. This will restart the ignition cycle. The first start-up of the heater may require several ignition cycles before all air is purged from the propane lines.

If the burner will not come on, the following items should be checked before calling a service person:

1. Switch turned off.
2. Propane supply to heater is empty or turned off.
3. Reset button on ECO is tripped.
4. If burner fails to light, call a Suburban Service Center or a local RV service agency.


#### **OPERATING INSTRUCTIONS—ELECTRIC ELEMENTS**

Electric water heaters are designed to operate with a minimum amount of service problems, however, proper operation and care is essential.

By far the most common trouble with electric water heaters results from energizing the water heater before it is filled with water. Even brief operation of the electric element without water in the tank will burn out the electric heating element as soon as 30 seconds.

Before the electric element will operate, the switch located behind the water heater door in the lower left corner of the control housing must be in the “ON” position.

To energize the electric element, locate the switch, which is on the bottom of the monitor panel, inside the RV and turn the switch marked “ELECTRIC” to the “ON” position. The water heater temperature will be regulated by the thermostat.

	<h2>WARNING</h2>
<p><b>It is imperative that the water heater tank be filled with water before operating the water heater. Operation of the water heater without water in the tank will result in damage to the tank, heat element, and/or controls. This type of damage IS NOT COVERED under warranty.</b></p>	





## CAUTION

The thermostat on your water heater is not adjustable. It is a temperature sensing limit designed to maintain a water temperature of 130 degree F (54 degree C ). Water temperatures over 130 degree F (54 degree C ) can cause severe burns instantly or death from scalds; therefore, be careful when using hot water. Children, disabled and elderly are at highest risk of being scalded. Always feel water before bathing or showering.



## WARNING

If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.



## CAUTION

When the recreational vehicle is not in use or while traveling, it is recommended that the propane supply also be turned off at the bottle.



## WARNING

If the user of this appliance fails to maintain it in the condition in which it was shipped from the factory or if the appliance is not used solely for its intended purpose or if the appliance is not maintained in accordance with the instructions in this manual then the risk of a fire and/or the production of carbon monoxide exists which can cause personal injury, property damage or loss of life.

#### TO TURN OFF WATER HEATER:

1. Turn switch to "OFF" position.
2. Turn off the electric power to the appliance.
3. Turn off propane supply.
4. If the vehicle is to be stored or the water heater is going to be turned off while subject to freezing temperature, drain the water heater.



#### Winterizing Your Water Heater

If your water heater plumbing system is equipped with a bypass kit, use it to close off the water heater. Drain the water heater completely and leave the water heater closed off (out of the system) in the bypass position particularly if you are introducing antifreeze into the plumbing system.

Antifreeze can be very corrosive to the anode rod creating premature failure and leave sediment in the tank. If the plumbing system is not equipped with a bypass kit, and you intend to winterize by adding antifreeze to the system, remove the anode rod (storing it for the winter) and replace it with a 3/4 inch drain plug.

#### REFRIGERATOR

Performance of refrigerators depends on various factors, such as, energy, venting, leveling, humidity and atmospheric heat temperatures, but not limited to these. All refrigerators are designed with absorption type of cooling units requiring careful leveling and venting condition or 12 volt DC compressor units.

**Leveling:** The refrigerator is made to operate within 3 degrees off level side-to-side and 6 degrees off level front-to-back ( as looking at the front of the refrigerator ). Operating it at more then these limits can cause damage to the cooling system and create a risk of personal injury or property damage. Make sure the vehicle is level before you operate the refrigerator.

Even being off only 1 degree will be uncomfortable living as 1 degree equals 5 inches higher from one end to the other in a 30 foot travel trailer.

## Operation During Travel

While the refrigerator should be level when the vehicle is stopped, performance during travel is not usually effected.

## Venting

For an absorption unit to operate fully it must have two vents. The lower vent serves as access to service components and allows air to enter. As the refrigerator heats up, warm air leaves through the upper vent in the roof or the upper side vent. The roof vent gives the best "chimney" results. However with correct baffles, side vent is good. All vents must prevent birds and rodents from entering.

## Moisture Reduction Heater

The refrigerator has a heater that prevents moisture from forming on the center divider between the doors of the freezer and the fresh food compartment. The heater operates only when the refrigerator is ON.

## Door Sealing

Check the seal of the doors.

If either door does not seal correctly, excess frost will collect inside the refrigerator. Make sure the doors seal correctly.

- \* Close each door on a piece of paper that is about the size and thickness of a dollar bill.


- \* Gently pull the paper.

- \* You should feel a slight drag between the gasket and the cabinet.

- \* Do this on all four sides.

- \* If you do not feel a slight drag on the paper, the door does not seal correctly.


- \* Have your dealer or an authorized Norcold Service Center correct the seal of the door.



### Door Handles

During travel, the door latch prevents the door from opening. When closing each door, push the door toward the refrigerator until you hear a “clicking sound”.

To open each door, pull the handle away from the refrigerator.



### Refrigerator Storage

Before the refrigerator is stored for an extended (seasonal) period of time:

- Defrost and clean the interior of the refrigerator.

If the refrigerator is stored for an extended period of time, before start up:

Make sure there are no obstructions in the vents, the ventilation air pathway, the burner, the orifice, or the flue area.

**For Defrosting and Cleaning the Refrigerator Interior, and other additional information and operating procedures, see the manual being supplied by the manufacture.**

For full operation details of all of the buttons and it's function on the control panel, refer to the Norcold refrigerator owners manual.

### OPERATING THE REFRIDGERATOR CONTROLS

1. On the right hand of control panel is an ON/OFF switch/button to activate unit.
2. The second button( center) will select the type of energy you choose to use for operation.
3. Third button is for temperature setting with 9 being the coldest.

**Additional information will be found in manufacturer's manual.**

## **AIR CONDITIONER—ROOF or SIDE**

Normal air conditioner is placed on top of roof and all controls are inside on air box. See instructions supplied by the manufacturer of product.

A possible future air conditioner may be placed in the sidewall, near roof line and will installed only by factory personnel.

Both air conditioners operate on 120 VAC power only.

## **MONITOR PANEL**

Your panel through modern technology will supply the charge condition of your battery, and water level information from your water tanks.

Operation requires 12-volt DC power, supplied by the battery or converter. Sensors, one negative and three positive, attached to a resistor, feed information to the display panel. To operate, place finger on button and push. A light will illuminate indicating the water level of tanks or charge condition of battery. "Gallery" will light only when floor plan includes the second gray water holding tank.

The switch on the lower left corner is for water pump operation. When in the "ON" position, pump will run until 40 to 45 PSI is achieved. The pump will shut off and restart at 20 pounds of pressure. Turn pump switch "OFF" when pump is not in use.

The red switch in the middle at the bottom of monitor panel is for the Water Heater LP gas. Red switch, lower right hand corner is for Water Heater electric.

When pushing the battery button, the highest light coming on indicates the battery condition: C -charge at 12.7 volts; G-good at 11.9 volts; F-Fair at 11.2 volts; L-low at 6.0 volts. Press only one button at a time as one set of lights serves all functions.



If problems occur with any appliance while traveling, contact the appliance manufacture direct. These phone numbers are listed in the appliance manuals. Manuals should stay in unit at all times.

### **OUT SIDE KITCHEN**

1. Cook top is a 2 burner hot plate and has no standing pilot light. Each use requires re-lighting the burner. Removable propane hose is included with quick connectors for propane.
2. A 120 volt AC refrigerator, compressor type is included. Small unit is 1.6 and large is 3.2 cu. feet. No 12 volt or propane is available.
3. Small sink and faucet is also a part of kitchen. Drainage of used water will drain into holding tank. An outside shower/ port is included with hose.
4. Several other items are available on larger coaches.

PLEASE NOTE, NOT all of these items can be in one kitchen.

### **WARNING**

1. When using cooking area, vehicle **MUST** be level and established.
2. **DO NOT** violate manufacturer's instructions on required clearances during use.
3. **DO NOT** store cooking appliances until cool to touch.
4. Can lead to fire or explosion plus death or serious injury.

Sonic coaches are pre-wired for portable solar panel, rear view camera, and "safe tek" charging components.

